


# KNQZE

*Personal Care*

## User Manual

Foldable Foot Spa Massager

Model: SL-FB1





# CONTENTS

Introduction .....	01
Package List .....	01
Product Specifications .....	01
Important Safety Precautions .....	01~02
Warning .....	03
Operation Instruction .....	03
How to Open Battery Door .....	03
Troubleshooting .....	04
Care And Maintenance .....	04
Warranty & Customer Support .....	04

## Introduction

Thank you for purchasing the KNQZE Foldable Foot Spa Massager with Heat, Bubbles and Mechanical Massage Rollers. Please read this user manual carefully and keep it in a safe place for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

### Note:

1. The product was filled with water for function test before leaving the factory. It's a normal phenomenon if there are residual water drops. Please use at ease.
2. Suggested to add warm water in order to heat it quickly.

## Package List

1 x Foldable Foot Spa Massager

1 x Foot Spa Massager Cover

1 x Remote Control

1 x User Manual

## Product Specifications

Name	Foldable Foot Spa Massager
Tub Material	PP & ABS plastic
Net Weight	3.96 lb
Unfolded Size	16*13.5*9 in
Folded Size	16*13.5*4.5 in
Power Support	AC120V~60HZ-500W
Temperature Range	Range: 105.8°F~113°F

## Important Safety Precautions

Read all the instructions carefully before use.

## **WARNING-REDUCE THE RISK OF BURNING, FIRE, ELECTRIC SHOCK OR PERSONAL INJURY**

1. When the appliance is connected to the power supply, it should not be left unattended, and the plug should be unplugged when not in use and when the component is retracted or removed.
2. Children over 8 years of age, people with disabilities, the mentally retarded, the elderly and insensitive to heat and cold should use this product with the help of others.
3. Please check whether the product is in good condition before use. If the power cord or plug of the product is damaged and cannot work normally, or falls into water, it shall not be used again. It shall be sent to the service center for inspection and maintenance.
4. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person to avoid danger.
5. Do not carry this product through the power cord or use it as a handle. Make sure the power cord and plug are dry and away from heat source. No foreign body shall be inserted or dropped into any opening.
6. Do not operate in areas where spray or oxygen is too much.
7. Do not operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and the like.
8. When you want to disconnect the power supply, you should first set the product not to work, and then unplug it.
9. Wet hands should not touch the plug and switch to avoid electric shock. For indoor use only, not for outdoor use.


## WARNING

- You must fill in water before turning on the foot bath massager.
- Never try to operate this device without water inside.
- Please don't pour hot water over 125 °F, it will trigger the over-temperature protection fail to boot.
- Please ensure the unit is off or disconnected from the power source when filling with water or cleaning.

## Operation Instruction

1. Place the appliance horizontally and remove the cover.
2. Unfold the appliance from folded to unfolded and fix the support rod to the buckle.
3. Add warm water to the half height of the soaker and plug in the power plug.
4. Press the power button to turn on all functions: heating, red light and bubble. With remote control, you can use it to control all the functions and set the temperature with 3 levels (Low Temp: 105.8°F=Blue Light / Mid Temp: 109.4°F=Purple Light / High Temp: 113°F=Red Light). The default temperature is 107.6°F(Blue Light) when the appliance is turn on. After setting the temperature, the appliance will heat the water to the temperature and keep constant.
5. After use, please turn off the appliance and unplug the power cord.
6. Twine the power cord around the winder under the bottom.
7. Put the cover on the appliance and store it in a clean and dry place.

### ● How to Open The Battery Door ?



## Troubleshooting

If the following problems cannot be solved, please contact our professional after-sales team to solve. Email: [knqzeservice@gmail.com](mailto:knqzeservice@gmail.com)

Problem	Cause	Solution
The heating function does not work.	The product is not connected to the power supply.	Check and connect the product to the power supply.
The product does not work.	The product is not activated properly after connected to the power supply.	Please use the product strictly following the user manual.
Stop work in the middle of using.	Check if the product has been used for too long.	Stop the machine and restart it 30 minutes later.
Leakage	Leaking at the bottom.	Plug off timely and check the quality of product.

## Care And Maintenance

### Drainage:

- Before draining, turn off the device and unplug the unit and allow it to cool.

### Clean:

- Clean only with a soft, damp cloth and mild cleansing agent.
- DO NOT immerse the massager in water or under faucet to do cleaning.
- If there is any dirt on the strainer/medicine box, take the strainer out and remove the dirt and rinse out with water.

### Storage:

- Before storage, wipe off any residual moisture with the dry cloth or towel to avoid mold.
- Store it in a clean and dry place.
- Never put the appliance close to fireplace or other heating sources.

## Warranty & Customer Support

If you need any assistance or support, please contact us via amazon or our service mail by offering Order ID & Problem Description. We will do our best to give you a viable solution.

Email: [knqzeservice@gmail.com](mailto:knqzeservice@gmail.com)

Shenzhen Weiyichuang Technology Co., Ltd  
Email: KNQZEservice@gmail.com  
Address: Bantian International Central, Longgang  
District, Shenzhen Guangdong, 518000



Made in China