


ivation®

Portable Camping Shower Kit with Rechargeable Batteries

SKU: IVAPSKIT

User Guide



Thank you for purchasing the Ivation Portable Camping Shower Kit with Rechargeable Batteries. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty.

Please read all directions before using the product and retain this guide for reference. This product is intended for outdoor use only. It is not intended for commercial use.

This product is covered by a limited one-year warranty. Coverage is subject to limits and exclusions. See warranty for details.

TABLE OF CONTENTS

3	SAFETY PRECAUTIONS
5	PRODUCT OVERVIEW
6	USAGE
10	CARE
11	SPECIFICATIONS
12	WARRANTY
13	GET IN TOUCH!


⚠ WARNING! Please read and understand all safety precautions, installation instructions, and operating instructions before operating this appliance. Failure to properly follow the guidelines established here could result in severe injury, fire, or even death. Keep this manual for future reference.

⚠ WARNING: CHOKING HAZARD — Small parts. This product contains small parts and is not suitable for children under 3 years old.

- Remove all packaging before using this device. Please keep all packaging materials out of reach of children and pets.
- Make sure charger port is closed tight before using, and do not put the battery supply into water.
- Ensure that the base of the pump is fully submerged in water before operation.
- Do not remove the pump from water while it is operating. Power off the battery before removing the pump.
- Ensure the shower head is securely mounted before use.
- Use only as described in this manual with manufacturers' recommended attachments and replacement parts.
- Operate only with water temperatures of 50 °F – 122 °F (10 °C – 50 °C).
- Do not modify or alter this appliance.
- This product is intended only for the use described in this manual. Do not use any parts or accessories that are not included with this product.
- Do not use the shower with water from the sea, pool, river, or any liquid other than water.

- When the shower is operated by children, proper instruction and supervision should be given.
- When not in use, always turn the unit off and remove from water.
- Recharge the battery using specification required. Output: DC 5 V / 1 A – 2 A.
- Do not charge the battery overnight or overcharge.
- Do not use this product if the power cord is damaged.
- Charge this appliance only with the correct voltage as listed on the shower plate (3.7 V). Using improper voltage may result in damage to the motor and possible injury to the user.
- Keep the shower away from fire or other heat sources.
- Do not use this product in harsh weather conditions, as this can damage the motor and cord.
- Do not remove the cover plate or attempt to disassemble this product. This will void all warranties.

PACKAGE CONTENTS




- | | |
|---------------------------------|-------------------------------|
| 1. Shower handle | 9. Shower head suction holder |
| 2. Stainless-steel outlet sheet | 10. Hook shower head holder |
| 3. O-ring | 11. USB charging cable |
| 4. Hose connector | 12. Handheld sprayer |
| 5. Hose | 13. Carrying bag |
| 6. Pump | 14. 15 L foldable bucket |
| 7. Filter cover | |
| 8. Battery pack | |


CHARGING THE BATTERY

It is recommended to charge the battery before using this product for the first time.


1. Remove the battery pack from the main device.



2. Plug the round end of the charging cable into the battery pack.



3. Plug the USB end of the charging cable into any of the following power sources (not included):
 - a. Mobile phone charger (charge time: 3.5 hours)
 - b. USB output from a laptop (charge time: 4 hours)
 - c. USB output from a vehicle (charge time: 3.5 hours)




The indicator light next to the plug will glow red while charging and blue when fully charged.


USING THE PORTABLE SHOWER

NOTE: Make sure appliance is disconnected from power supply before starting the installation process.


1. Attach the shower handle and pump to both ends of the hose with the hose connectors.




2. Choose which shower holder you wish to use:
 - a. Use the hook shower head holder to hang the shower head from a pole or tree branch.




b. To secure the shower head suction holder to a flat surface, make sure the switch with the “Thumbs Up” is pulled forward. Place the suction cup on a compatible surface (for example: glass, tile, wall, etc.). Once flush against the surface, press the “Thumbs Up” switch forward so it locks in place.



3. Secure cord from the pump into the battery pack by lining up the flat ends of the plug with the flat ends of the battery pack outlet (the same outlet that is used to charge the battery pack). Once the pump cord is in place, turn the plug clockwise until tight and secure.




4. Immerse the pump into a clean water source.
NOTE: Do not submerge the battery pack. This may result in an electric shock and/or damage to the shower.




5. Press and hold the on/off button for three (3) seconds to start.


NOTE: When finished, always turn off the power before removing the pump from water. Running the pump while it is not submerged may result in damage.



6. Turn the shower head down to start the showering:



7. Push the shower head up to stop:




GENERAL MAINTENANCE

- Stop the device by pressing the on/off button of battery pack and remove the battery pack from the power cord.
- Take out the pump from water and remove the handheld sprayer or shower handle from hose.
- Drain all water from the hose before storing.
- Store the pump away from extreme temperatures.

CLEANING THE FILTER

- Remove the filter cover by twisting it counterclockwise.
- Clean the filter and filter cover with water and a mild detergent.



BATTERY PACK MAINTENANCE:

- We recommend charging the battery to 40% - 50% (approx. 1 - 2 hours) after each use to ensure the maximum battery life. Please charge before using for the first time.
- Please recharge the battery at least every three (3) months to ensure it remains at least a 40% - 50% charge — the battery will deplete when stored for long periods.
- Do not charge the battery beyond output specification the products required (Output: 5 V / 1 - 2 A).
- Store away from high temperatures or flammable & explosive goods.
- Only use the charging cable provided with unit and do not overcharge the unit.
- Do not use the charger with the output higher than 5 V to charge the battery pack, it may damage the battery and cause fire or explosion.

Voltage:	3.7 V
Max current:	3 - 3.5 A
Flow rate:	2.5 - 3.5 L/min
Capacity of battery:	2200 mAh
Usage time:	40 - 50 mins
Hose length:	5.9 ft.
USB charging cable length:	2.6 ft.
Power supply:	Rechargeable lithium battery packs
Charging output:	Any USB output of 15 V, 1 - 2 A
Charging time:	3.5 - 4 hours
Product type:	Camping shower kit
Accessories:	1 shower head suction holder, 1 hook holder with suction cup
Installation required:	No
Additional tools required:	No
Warranty included:	Yes
Color:	White
Hose color:	Gray
Location:	Indoor or outdoor use
Adult assembly required:	Yes
Country of origin:	China
Warranty length:	1 year

WARRANTY INFORMATION

This Ivation Portable Camping Shower Kit with Rechargeable Batteries ("Product"), including any accessories included in the original packaging, as supplied and distributed new by an authorized retailer is warranted by C&A Marketing, Inc. (the "Company") to the original consumer purchaser only, against certain defects in material and workmanship ("Warranty") as follows:

To receive Warranty service, the original consumer purchaser must contact the Company or its authorized service provider for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented to the Company or its authorized service provider in order to obtain the requested service.

Service options, parts availability, and response times may vary and may change at any time. In accordance with applicable law, the Company may require that you furnish additional documents and/or comply with registration requirements before receiving warranty service. Please contact our customer service for details on obtaining warranty service:

info@myivation.com

1-866-849-3049

Shipping expenses to the Company's Return Facility are not covered by this warranty and must be paid by the consumer. The consumer likewise bears all risk of loss or further damage to the Product until delivery to said facility.

EXCLUSIONS AND LIMITATIONS

The Company warrants the Product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a hardware defect arises and a valid claim is received within the Warranty Period, the Company, at its sole option and to the extent permitted by law, will either (1) repair the Product defect at no charge, using new or refurbished replacement parts, (2) exchange the Product with a Product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original device, or (3) refund the purchase price of the Product.

A replacement Product or part thereof shall enjoy the warranty of the original Product for the remainder of the Warranty Period, or ninety (90) days from the date of replacement or repair, whichever provides you longer protection. When a Product or part is exchanged, any replacement item becomes your property, while the replaced item becomes the Company's property. Refunds can only be given if the original Product is returned.

This Warranty does not apply to:

- (a) Any non-Ivation Portable Camping Shower Kit with Rechargeable Batteries product, hardware or software, even if packaged or sold with the Product;
- (b) Damage caused by use with non-Ivation Portable Camping Shower Kit with Rechargeable Batteries products;
- (c) Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes;
- (d) Damage caused by operating the Product outside the permitted or intended uses described by the Company;
- (e) Damage caused by third party services;
- (f) A Product or part that has been modified to alter functionality or capability without the written permission of the Company;
- (g) Consumable parts, such as batteries, fuses, and bulbs;
- (h) Cosmetic damage; or
- (i) If any Ivation Portable Camping Shower Kit with Rechargeable Batteries serial number has been removed or defaced.

This Warranty is valid only in the country where the consumer purchased the Product, and only applies to Products purchased and serviced in that country.

The Company does not warrant that the operation of the Product will be uninterrupted

or error-free. The Company is not responsible for damage arising from your failure to follow instructions relating to its use.

NOTWITHSTANDING ANYTHING TO THE CONTRARY AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE COMPANY PROVIDES THE PRODUCT "AS-IS" AND "AS-AVAILABLE" FOR YOUR CONVENIENCE AND THE COMPANY AND ITS LICENSORS AND SUPPLIERS EXPRESSLY DISCLAIM ALL WARRANTIES AND CONDITIONS, WHETHER EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, QUIET ENJOYMENT, ACCURACY, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS. THE COMPANY DOES NOT GUARANTEE ANY SPECIFIC RESULTS FROM THE USE OF THE PRODUCT, OR THAT THE COMPANY WILL CONTINUE TO OFFER OR MAKE AVAILABLE THE PRODUCT FOR ANY PARTICULAR LENGTH OF TIME. THE COMPANY FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE.

YOU USE THE PRODUCT AT YOUR OWN DISCRETION AND RISK. YOU WILL BE SOLELY RESPONSIBLE FOR (AND THE COMPANY DISCLAIMS) ANY AND ALL LOSS, LIABILITY, OR DAMAGES RESULTING FROM YOUR USE OF THE PRODUCT.

NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM THE COMPANY OR THROUGH ITS AUTHORIZED SERVICE PROVIDERS SHALL CREATE ANY WARRANTY.

IN NO EVENT WILL THE COMPANY'S TOTAL CUMULATIVE LIABILITY ARISING FROM OR RELATED TO THE PRODUCT, WHETHER IN CONTRACT OR TORT OR OTHERWISE EXCEED THE FEES ACTUALLY PAID BY YOU TO THE COMPANY OR ANY OF ITS AUTHORIZED RESELLERS FOR THE PRODUCT AT ISSUE IN THE LAST YEAR FROM YOUR PURCHASE. THIS LIMITATION IS CUMULATIVE AND WILL NOT BE INCREASED BY THE EXISTENCE OF MORE THAN ONE INCIDENT OR CLAIM. THE COMPANY DISCLAIMS ALL LIABILITY OF ANY KIND OF ITS LICENSORS AND SUPPLIERS. IN NO EVENT WILL THE COMPANY OR ITS LICENSORS, MANUFACTURERS, AND SUPPLIERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA, OR RECORDS) CAUSED BY THE USE, MISUSE, OR INABILITY TO USE THE PRODUCT.

Nothing in these terms shall attempt to exclude liability that cannot be excluded under applicable law. Some countries, states, or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so certain limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

GET IN TOUCH!

✉ info@myivation.com

☎ 1-866-849-3049

IVATION is a trademark of C&A IP Holdings LLC in the US, Canada, and the EU.

All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement, or approval.

Distributed by C&A Marketing, Inc., 114 Tived Lane East, Edison, NJ 08837. Made in China.

© 2021. C&A IP Holdings LLC. All Rights Reserved.