



User Manual

Model: H705E

Govee Permanent Outdoor Lights 2

READ AND SAVE THESE INSTRUCTIONS

Safety Instructions


- This string light is rated as IP67 Waterproof. It can be used outdoors but cannot be immersed in water for a long time.
- The control box is rated as IP65. It can be used outdoors but cannot be immersed in water.
- The power adapter is used for indoor dry location.
- Risk of Electric Shock. The adapter install only to a covered Class A GFCI receptacle that has an enclosure that is weatherproof with the attachment plug cap inserted or removed.
- To prevent the string light from falling down, ensure it is installed with both the adhesive tape and the clips.
- Tighten up the waterproof cap before using the light.
- Do not allow children to assemble and install this product.
- Avoid installing this product near major heat sources or other dangerous sources.

- Avoid using other non-standard adapters for this product.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.
- To reduce the risk of strangulation, the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.

What You Get

Item	Quantity
String Light	6
Power Adapter	1
User Manual	1
Quick Start Guide	1

At a Glance




- a. Power Adapter
- b. Control Box
- c. Permanent Lights
- d. Waterproof Connector



- Press to turn on or off.
- Press and hold for 5 seconds to reset.

Disassembly Tip



The product is divided into two parts: (1) a light source and (2) an adapter. By detaching the output terminal of the adapter, you can easily remove the light source or the adapter.

Pairing Your Light with Govee Home App

What You Need

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 and above or Android 4.3 and above.



- 1 Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
- 2 Turn on your smartphone's Bluetooth.
- 3 Open the app, tap the "+" icon in the top right corner and search for "H705E."
- 4 Tap the device icon and follow the on-screen instructions to complete pairing.

Controlling the Light with Your Voice

- ❶ Open the app, then tap the device icon to enter the details page.
- ❷ Tap the settings icon in the top right corner.
- ❸ Select User Guide and follow the on-screen instructions to control the device using your voice.

Specifications

Power Input (Adapter)	200-240VAC 50/60Hz
Power Input (Light)	36VDC 2A
Length	100ft
Waterproof	String Light: IP67 Control Box: IP65
Light Displaying Technology	RGBWIC
Color Temperature	4000K
Maximum Extension Length	150ft

Troubleshooting

❶ The light does not work./Part of the light does not light up.

- a. Check whether the adapter is working properly. A dim green light will appear at the front side of the adapter (close to the output end) when the U.S. standard adapter is in the normal working state.
- b. Go to the details page of the light in the app. Tap the settings icon in the upper right corner and adjust in Settings of Number of Segments.
- c. Make sure you have connected the wire connectors between the string lights.
- d. Long press the control box for more than 5s to reset the whole light.
- e. Remove the last string light that lights up. Then, connect each string light that cannot light up with the remaining string lights that can light up properly. Repeat this step until you find the malfunctioning string lights.

❷ Cannot connect to Wi-Fi.

- a. Do not skip the Wi-Fi connection steps in the app.
- b. Make sure your home Wi-Fi is 2.4Ghz and your smartphone's Bluetooth is on.
- c. Long press the control box for more than 5s to reset the whole light. Unbind and then rebind the light.

- d. Connect your smartphone to Wi-Fi and check whether the network works well.
- e. Make sure you have entered the correct Wi-Fi name and password.
- f. If the light is too far away from the Wi-Fi, bring the device closer to the Wi-Fi, and then reconnect to the network.
- g. Check if there are too many devices connected to the network. If so, change to another network.

③ The adhesive tape is not strong enough.

- a. Use the clips to secure the light firmly during installation.
- b. Make sure the installation surface is dust-free, smooth and dry before installation.
- c. The 3M adhesive will be less sticky after being used once. Do not stick repeatedly. If you accidentally stick it wrong or the adhesive falls off, replace the adhesive with a new one and try again.
- d. If the roof surface is rough, it is recommended to use clips with screws for installation.
- e. Due to the nature of the adhesive, the initial tack is low at low temperatures. Try to warm up the adhesive as well as the installation location to achieve the best installation result.

4 App operation guide is needed

- a. Open Govee Home App, tap My Profile>> Govee Instructions>> App Guide>> How to Use to find more details.

5 For other issues

- a. Please contact the Govee support team.

Customer Service

 Warranty: 36-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome



User Manual

Model: H7038

Govee Outdoor String Lights 2

Safety Instructions

- This product is rated as IP65 Waterproof. It can be used outdoors but cannot be immersed in water.
- Tighten up the waterproof cap before installing the light.
- The internal light sources of the light cannot be replaced. If the light sources sustain damage, the product should be replaced.
- Do not allow children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.

Introduction


Thanks for choosing the Govee Outdoor String Lights 2. This product has an IP65 waterproof rating, making them ideal for outdoor use. Using Govee Home App, you can adjust its color and brightness and sync its lighting effects with rhythm by turning on Music Mode.

What You Get

Item	Quantity
String Light	2
Adapter	1
Control Box	1
Cable Clip	15
User Manual	1


At a Glance

- Press to turn the light on or off.
- Long press for 5 seconds to reset.




Controlling String Lights in Series

1. Connect the two string lights as shown in the image.



2. Firmly screw the wire nut.




Note: Only 3 string lights can be connected in a series.


Installing Your Device

Installation Steps

Use the hooks to hang the light bulbs onto the string.



- 1 Find a proper position and firmly fit the cables into the cable clip.



Pairing Your Device with Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS or Android.



- 1 Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
- 2 Turn on your smartphone's Bluetooth.
- 3 Open the app, tap the "+" icon in the top right corner and search "H7038."
- 4 Tap the device icon and follow the on-screen instructions to complete pairing.

Specifications

Power Input	100-240VAC 50/60Hz
Power Output	36VDC 1.5A
Total Length (including control box and power adapter)	98FT/30M
Light Color	RGB+Warm White
Waterproof	Control Box (IP65) String Light (IP65)
Working Temperature	-20°C-40°C / -4°F-104°F

Troubleshooting

- ❶ Failed to connect to Govee Home App.
 - Make sure the string lights are connected to power.
 - Make sure your smartphone's Bluetooth is enabled.
 - Keep your smartphone close to the control box and try again.
- ❷ Missing parts/Receiving products from a secondary sale.
 - Check the pictures on the web page to confirm what parts are missing and contact customer service in the app for replacements.
 - If you received a product from a secondary sale or a product that cannot work properly, please contact customer service in the app for a replacement.
- ❸ Network failure
 - Make sure your home Wi-Fi is 2.4Ghz, and your smartphone's Bluetooth is on.
 - Long press the control box for more than 5s to reset the whole light. Unbind and then rebind the light.

- If the light is too far away from the Wi-Fi, bring the device closer to the Wi-Fi, and then reconnect to the network.
- Check if there are too many devices connected to the network. If so, change to another network.
- If the above methods cannot solve your problems, please contact customer service in the app to replace the control box.
- ④ App operation guide is needed.
- Open Govee Home App, tap My Profile>> Govee Instructions>> App Guide>> How to Use, to find more details.

If your problem persists, please contact Customer Support.

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome



User Manual

Model: H70B3
Govee Curtain Lights 2

Safety Instructions

- Move **all** cribs, beds, furniture and toys away from the **lights**. Do not tie the bottom of the string lights and form loops as this could wrap around a child's neck and cause SUFFOCATION.
- This product is rated as **IP65 Waterproof**. It can be used outdoors but cannot be immersed in water.
- The internal **light** sources of the string lights cannot be replaced. If the light sources sustain damage, the product should be replaced.
- Do not **allow** children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter **only**.
- To reduce the risk of strangulation, the flexible wiring connected to this **luminaire shall** be effectively fixed to the **wall** if the wiring is within arm's reach.
- Keep **all** string lights out of the reach of children.


Introduction

Thanks for choosing the Govee Curtain Lights 2. These curtain **lights** are easy to **install** and can be used both indoors and outdoors. They can not **only** be used in/on curtains, bedrooms, bushes, dormitories, yards, balconies or any other places for lights and decoration, but **also** can be applied during holidays like Christmas, Valentine's Day and Halloween. With the DIY mode and Music mode, you can **also** design your own lighting effects and bring more fun to your parties.

What You Get


Item	Quantity
Curtain Light	1
Adapter	1
Control Box	1
User Manual	1

At a Glance



- ❶ Power Adapter
- ❷ Control Box
- ❸ Waterproof Connector
- ❹ Repeater
- ❺ Wire Adapter
- ❻ Hooks
- ❼ Plastic Strap

- Press to turn the light on or off.
- Long press for 5 seconds to reset.



Pairing Your Device with Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS or Android.



1. Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
2. Turn on your smartphone's Bluetooth.
3. Open the app, tap the "+" icon in the top right corner and search "H70B3."
4. Tap the device icon and follow the on-screen instructions to complete pairing.

Specifications

Power Input	AC 100-240V(US Plug) AC 200-240V (EU&BS Plug)
Power Output	36VDC 1A
Size	4.9ft*6.5ft(1.5m*2m) / PCS
Light Color	RGB
Waterproof	Control Box (IP65) String Light (IP65)
Working Temperature	-20-40°C/-4-104°F

Troubleshooting

1. Failed to connect to Govee Home App.

- Make sure the curtain lights are connected to power.
- Make sure your smartphone's Bluetooth is enabled.
- Keep your smartphone close to the control box and try again.

2. Missing parts/Receiving products from a secondary sale.

- Check the pictures on the web page to confirm what parts are missing and contact customer service in the app for replacements.
- If you received a product from a secondary sale or a product that cannot work properly, please contact customer service in the app for a replacement.

3. Network failure

- Make sure your home Wi-Fi is 2.4Ghz, and your smartphone's Bluetooth is on.
- Long press the control box for more than 5s to reset the whole light. Unbind and then rebind the light.

- If the light is too far away from the Wi-Fi, bring the device closer to the Wi-Fi, and then reconnect to the network.
 - Check if there are too many devices connected to the network. If so, change to another network.
 - If the above methods cannot solve your problems, please contact customer service in the app to replace the control box.
4. App operation guide is needed.
- Open Govee Home App, tap My Profile>> Govee Instructions>> App Guide>> How to Use, to find more details.
- If your problem persists, please contact Customer Support.

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome