

CONGRATULATIONS ON YOUR PURCHASE OF THE LIGHT UP ELECTRONIC WORD CLOCK.

Please read all instructions and warnings prior to use. Keep this manual as it contains important information for future reference.

SHARPER IMAGE® NAME AND LOGOS (INCLUDING THE 77 LOGO, TOMORROW'S TOMORROW, AND SPASTUDIO) ARE TRADEMARKS OR REGISTERED TRADEMARKS. DISTRIBUTED BY AND © 2018, 2020 MERCHSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS RESERVED.

FOR CUSTOMER SUPPORT, PLEASE CALL 1-800-374-2744.

Printed in China.



SHARPER IMAGE®

LIGHT UP ELECTRONIC WORD CLOCK

SAFETY WARNINGS PLEASE READ ALL SAFETY WARNINGS BEFORE USE

- Do not use attachments of any kind.
- For indoor use only.
- Do not expose to extreme temperatures or moisture.
- This item does not have serviceable components. Do not disassemble.
- Not intended for children under 14 years of age.
- Do not submerge in water.
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC STATEMENT

CONTENTS

- Word Clock
- USB Power Cord
- USB Adapter



Reads: IT IS TWELVE O'CLOCK

- ◀ Time Advance
- ◀ Time Reverse
- ◀ Power Port



Reads: IT IS FIFTEEN MINUTES TO THREE



Reads: IT IS TEN MINUTES PAST FOUR

POWER

The Word Clock is powered by connecting the included USB cable and Adapter to a power outlet or by connecting the cable to a 5V USB port.

Use UL certified adapter only (5V DC, 1A).

SETTING THE CLOCK

1. Connect the clock to a power source. The words will flash 2 times.
2. The clock will display "It Is Twelve O'Clock" (right).
3. Move the time forward by pushing and holding the Time Advance button, or backwards by pushing and holding the Time Reverse button.
4. When you have reached the desired time, release the button and the clock will display the time in five minute segments.

READING THE CLOCK:

- Every five minutes, the clock will change its display.
- The clock is read from top to bottom.
- The clock displays the time in terms of minutes past the hour up to 30 minutes and then minutes until the hour.
 - o It is: Five Minutes Past, Ten Minutes Past, Fifteen Minutes Past, Twenty Minutes Past, Twenty Five Minutes Past, Thirty Minutes Past (Hour).
 - o It is: Twenty Five Minutes To, Twenty Minutes To, Fifteen Minutes To, Ten Minutes To, Five Minutes To (Hour).