


MOTORBOX
PREMIUM SEAT COVER




INSTRUCTION GUIDE
F R O N T S E A T C O V E R




Scan code for video demo

PARTS CONTENT:




1



PREPARE YOUR SEAT COVERS

- Attach a butterfly disc to each elastic strap on the front side of the seat cover (backrest).
- Attach a butterfly disc to each elastic strap on the rear side of the seat cover (seat bottom).
- Attach a wire hook to each elastic strap on the back side of the seat cover (backrest).
- Attach a wire hook to each elastic strap on the front side of the seat cover (seat bottom).


2



REMOVE HEADREST

Locate the locking tab at the base of the headrest. Press the tab and lift the headrest to release from its position. Please consult your vehicle's user manual for specifications.

3




INSTALL SEAT COVER (Backrest)

For easier installation, we recommend reclining your car seat.

- Place the seat cover over your car seat.
- Gently pull down the seat cover, make sure it is centered and facing forward.
- Insert the attached butterfly discs on the front of the seat cover into the gap between your car seat's backrest and seat bottom.


4



ANCHOR SEAT COVER (Backrest)

Once inserted through the gap, flip the butterfly disc vertically so that it is securely anchored.


5



INSTALL SEAT COVER (Seat Bottom)


- Place the seat cover on top of your car's seat bottom.
- Insert the attached butterfly discs on the rear of the seat cover into the gap between your car seat's backrest and seat bottom.

6




ANCHOR SEAT COVER (Seat Bottom)

Once inserted through the gap, flip the butterfly disc vertically so that it is securely anchored.



SECURE SEAT COVER (Seat Bottom)


Secure the attached wire hooks on the front of the seat cover to a sturdy point underneath your car seat. Avoid hooking onto any wires or components that could interfere with your vehicle's functionality.



BUCKLE SEAT COVER (Seat Bottom)

Method #1 - Buckle Under the Seat


Wrap the buckle straps underneath the seat and fasten the buckles together.



BUCKLE SEAT COVER (Seat Bottom)

Method #2 - Buckle Behind the Seat (With Wire Hooks)


- Lift up the skirt at the bottom of the backrest, in the rear.
- Wrap the buckle straps around the back and secure the buckles together.
- Reposition the rear skirt to conceal the buckle straps.



SECURE SEAT COVER (Backrest)

Method #2 - Buckle Behind the Seat (With Wire Hooks)


- Secure the attached wire hooks on the back of the seat cover to a sturdy point underneath your car seat. Avoid hooking onto any wires or components that could interfere with your vehicle's functionality.



BUCKLE SEAT COVER (Seat Bottom)


Method #3 - Buckle Behind the Seat (Without Wire Hooks)

- If you are unable to fasten the buckle underneath the seat, wrap the buckle straps around the back, through the elastic straps, and secure the buckles together.
- Reposition the rear skirt to conceal the buckle straps.




INSTALL HEADREST COVER

- Slide the headrest cover over the headrest. The side with the headrest tab is the front side of the headrest.
- Wrap the tab under the headrest and tuck it inside the headrest cover to fasten it.



FASTEN THE SEAT COVER (Backrest)

- Snap together the button fasteners on top of the seat cover to enclose the top area.
- Gently tuck the seat cover underneath the headrest base.
- Adjust seat cover as necessary.



REINSTALL HEADREST

- With the headrest cover installed, align the headrest posts with the headrest base. Press and hold the locking tab, then firmly push the headrest downward.
- Safely reinstall the headrest according to your vehicle's manufacturer instructions. Please consult your vehicle's user manual for specifications.



QUESTIONS

FREQUENTLY ASKED QUESTIONS

ANSWERS



1 ARE THE SEAT COVERS COMPATIBLE WITH HEATED SEATS?

1. MBOS seat covers are designed with materials that allow heat to pass through, ensuring the functionality of heated seats remains unaffected.



2 WHAT SHOULD I DO IF I DO NOT HAVE ACCESS UNDER MY CAR SEAT TO SECURE THE SEAT COVER STRAPS?

2. We recommend securely tucking the straps under the seat covers. You may also carefully cut off the straps, be sure to avoid cutting too close to the seams to prevent the stitching from unraveling.



3 HOW DO I GET RID OF CREASES ON THE SEAT COVERS?

3. It is normal for napa leather seat covers to have creases due to packaging. These creases typically relax on their own as the leather conforms to the seat's shape, which can take a few days to weeks, depending on usage and temperature. To speed up the process, you can use a gentle heat source like a hair dryer or a handheld steamer to remove the creases.



4 WHAT IS NAPA LEATHER?

4. Napa leather is a high-quality, soft, and supple leather typically made from full-grain or top-grain hides of animals like cow, lamb, or goat. It is known for its smooth texture and luxurious feel.



5 WHERE DO I ATTACH THE BUTTERFLY DISCS?

5. Two butterfly discs are used to attach to each elastic strap at the front of the seat cover (backrest). Please refer to steps 3 and 4 of the installation guide.

Two butterfly discs are used to attach to each elastic strap at the back of the seat cover (seat bottom). Please refer to steps 5 and 6 of the installation guide.



QUESTIONS

FREQUENTLY ASKED QUESTIONS

ANSWERS



HOW DO I ATTACH THE BUTTERFLY DISCS?

6. Locate the two openings on the butterfly disc. Open the loop on the elastic strap and insert it into one of the openings on the butterfly disc. Rotate the butterfly disc and insert the elastic strap into the other opening on the butterfly disc. Gently pull the butterfly disc to confirm it is securely installed.



WHERE DO I ATTACH THE WIRE HOOKS?

7. Two wire hooks are used to attach to each elastic strap at the back of the seat cover (backrest). Please refer to step 10 of the installation guide.

Two wire hooks are used to attach to each elastic strap at the front of the seat cover (seat bottom). Please refer to step 7 of the installation guide.



HOW DO I ATTACH THE WIRE HOOKS?

8. Locate the opening on the wire hook. Open the loop on the elastic strap and insert it into the opening on the wire hook. For easier installation, gently twist the opening of the wire hook to create additional space. Be sure to twist the opening of the wire hook into a securely closed position after installing onto the elastic strap.



MOTORBOX

AUTOMOTIVE ACCESSORIES MANUFACTURING & DISTRIBUTION

TEL: (231) -310-3101 EMAIL: SUPPORT@CARXS.COM WWW.CARXS.COM