



4

ASSEMBLY INSTRUCTIONS

⚠ WARNING: For your own safety, never connect plug to power source outlet until all assembly steps are complete and you have read and understood the safety and operation instructions. Do not operate the vacuum with any parts damaged or missing.

INSTALLING THE CASTERS

- Turn canister over (upside down) so the black base is now on top.
- Locate the small diameter hole in a corner of the base and insert the caster stem into the hole. Using firm and steady pressure, press the caster downward until it will go no further. See figure 1.
- Insert the wheel into the canister bottom as shown in figure 2.
- Repeat the last step, installing a caster in each of the remaining 2 corners of the vacuum base.

INSTALLING THE FILTER, MOTOR AND HOSE

- Loosen the clasp and then take the head out of the container.
- Lower the fire prevention filter bag into the metal canister, rubber gasket at the top. See figure 3.
- Secure the motor housing in place by locking down the clamps. See figure 4.
- Insert the aluminum tube into the hose, then insert the other end of the hose into the air inlet. See figure 5.
- Turning the nozzle clockwise while pushing it into the hose end will help to securely seat the metal nozzle. See figure 6.

INSTALLATION OF BLOW FUNCTION

- Put the aluminum tube into the blower port and tighten. See figure 7.

ACCESSORY STORAGE

- Slide the narrow end of an extension tube into the Floor/Carpet Brush. Now slide the open extension tube end over one of the rings located above casters to store as shown in Figure 8.
- Slide the other accessories over the remaining rings for storage.

ON/OFF SWITCH

After plugging the power cord into an outlet, the unit is turned on by pushing the switch from position “O” to position “I”. The symbols used on the toggle switch are international “On & Off” symbols. “O” is the symbol for “OFF” and “I” is the symbol for “ON”.

O = OFF I = ON

5