





# 1





SRS-XB21

4-734-036-13(1)


©2018 Sony Corporation Printed in China



# 2




# 3







LIGHT






ON







OFF




Wireless Party Chain



Speaker Add



Android



Android / iPhone



<http://www.sony.net/smcapp/>



Wireless Party Chain Speaker Add Party Booster



[http://rd1.sony.net/help/speaker/srs-xb21/h\\_zz/](http://rd1.sony.net/help/speaker/srs-xb21/h_zz/)