




Pride User Manual

Illustration




1

Operating instruction



Remove empty oil bottle by twisting to the left.

Remove cap and reducer of 10 mL or 15 mL bottle of 100% pure essential oil, then twist it up to the nebulizer.



Battery charge

Low battery remind: Medium mode indicator is red and slow-flashing.

Low battery alarm: Medium mode indicator is red and quick-flashing.


In-charging: Battery indicator is yellow.

Charging Completion: Battery indicator is green.

2

3

Operating instruction



Power on

Press POWER for 3 seconds, 3 mode lights will flash till the nebulizer detects essential oil then operate under pre-set mode (default mode at "HIGH" for 1 hour).

Power off

- Press POWER for 3 seconds, 3 mode lights will be flashing for 20 seconds, then power off.
- When timer is up, the mode lights will be flashing for 20 seconds, then power off.


Mode selection

Press POWER to select (intermittent and cycling)

LOW: 10 seconds diffusing and pause for 190 seconds, LOW mode indicator light on.

MEDIUM: 10 seconds diffusing and pause for 30 seconds, LOW and MEDIUM mode indicator lights on.

HIGH: 10 seconds diffusing and pause for 10 seconds, LOW, MEDIUM and HIGH mode indicator lights on.



Timer selection

Press TIMER to select

- 1-hour work time, "1" light on.
- 2-hour work time, "2" light on.
- 4-hour work time, "4" light on.
- 8-hour work time, 3 indicators light off.

Refill reminder

When essential oil runs out, mode indicator will flash as a reminder until the unit detects a refill.

Care/Maintenance

- Only use the power cord supplied with the unit.
- Charge the unit for 4 hours before using with battery operation.
- Disconnect the adaptor from power source when not in use.
- Wipe the unit with a soft cloth.
- Only use 100% pure essential oil, Other types, such as fragrance and synthetic oils, may put the unit under unexpected condition and void its warranty.
- In case clearance of oil residual needed, fill alcohol in an empty bottle and diffuse for a while in a well-ventilated area.
- Please keep away from children.
- Disassemble may cause malfunctioning of the unit.
- The unit is not designed for outdoor use.

4

Trouble Shooting

No misting	<ul style="list-style-type: none">• Make sure the oil bottle is not empty.• Restart the unit.
------------	--

Specifications

Charger	Adaptor with rechargeable battery
Charging Time	Approximate 4 hours
Battery Duration	8 hours at Medium
Consumption	About 1 mL/h for High, 0.5 mL/h for Medium, 0.1 mL/h for Low
Noise Level	38 dB
Coverage	700 Square ft.
Voltage	DC 5V 1A
Oil Bottle	Applicable 10mL, 15mL
Product Size	L130*W42*H152mm
Gift Box	L190*W190*H50mm
Master Carton	L445*W207*H207mm (1*8)
Net Weight	0.28 KG (Product)
Gross Weight	5 KG (Master Carton)

5

6

7

8