

30W HAND-GRIP MEGAPHONE

Professional Compact Power Megaphone

QUICK GUIDE

Model: **PMP35R**




FEATURES

- Dry Cell Operation
- Full ABS Body, Sturdy & Lightweight
- Built-in Siren & Microphone
- Clear Sound, Long Range & Efficient Design
- Conveniently Located Volume Controls & Switch
- 10 Seconds Voice Recording Function

OPERATION

- Open the back cover by pressing down on the 'Open' Button
- Insert 4 x "D" Cells then close back cover until locks into position. Now, your megaphone is ready for operation.
- To activate the megaphone, press the 'ON/OFF' button on the back cover.
- When using the megaphone, place your lips as close as possible to the megaphone when speaking. Adjust the 'Volume Control' to the desired level without causing any howling or feedback.
- Press the 'Siren' button to activate emergency siren/alarm. To switch off the alarm, press the same button again, or press the 'ON/OFF' button.
- Adjust the volume control to the min. before recording. To record, press the SIREN button and the PLAY button together. Now your megaphone is ready for recording. The longest record time is about 10 seconds. Press the SIREN button and the PLAY button together after finishing recording.
- Press the PLAY Button to activate the recorded materials circularly.



PRECAUTIONS

Ensure correct polarity of cells used. Insert the batteries in the correct direction by aligning the (-) marks on the batteries with the spring in the back cover.

Use new batteries/cells whenever possible.

When the megaphone is not in use for a long period of time, remove the dry cells and replace.

Drained cells or rechargeable battery will not give sufficient sound volume.

SPECIFICATIONS

- **Power Output:** 30 Watts
- **Voice Range:** 800 Yards
- **Power Source:** 4 x UM – 1 Cells (Not Included)
- **Battery Life:** 6 – 8 Hours
- **Microphone:** Unidirectional
- **Dimensions:** Diameter: 6 1/4" x Length: 10 1/8"
- **Weight:** 1.15 LBS.

Design & Specifications subject to change without prior notice