


SKIL

BLOWER
8600 (F0158600..)



INSTRUCTIONS

page 4

使用说明

第 8 页

使用説明

第 11 頁

寸書

14 페이지

คู่มือ

หน้า 18

PETUNJUK

halaman 22

www.skil-ap.com



1 8600

600 Watt

1.7 kg

0-16000 RPM

3.3m³/min

2 Read operator's manual

3 SWITCH OFF: Remove plug from mains before cleaning or maintenance.

Caution

Do not use in the rain or leave outdoors while it is raining.

Wear eye protection.

Keep bystanders away.

