



Buttons

x2 Click	x1 Click	Hold down
Switching lamp effect	⏮	On / off
	🔊 +	⏭
	🔊 -	⏮
	TWS	Clear
	📶	Disconnect / Reject

Bluetooth connected

TWS Mode

ON when Slave TWS

A line drawing of the Surgeboom 2 device with arrows pointing to the various control buttons and their locations.

What's In The Box

QUICK START GUIDE

x1

x1

x1

Charging

ON/OFF

Low Battery

Fully Charged

A diagram showing the device being charged with a USB-C cable. It includes a battery status indicator showing 'Low Battery' and 'Fully Charged' with corresponding light icons.

Led Disco Light

x2

A diagram showing the device with four different LED light colors: yellow, red, green, and blue. A hand icon points to the light control button on the device.

Bluetooth Connection

Device name: Surgeboom 2

Bluetooth

x1

A diagram showing a smartphone connected to the device via Bluetooth. The device name 'Surgeboom 2' is displayed. Below the phone, icons for a smartphone, laptop, and tablet are shown.

Connectors

Aux In 3,5mm

(Audio cable not included in the package)

USB Type-C

A diagram showing the device with the Aux In 3.5mm and USB Type-C connectors. The USB Type-C connector is shown with a cable plugged in.

TWS Connect

Setp1: Select any one as the master and the other as the auxiliary

Setp2

Setp3

Setp4

Setp5

A series of five diagrams (Setp1 to Setp5) illustrating the steps to connect two Surgeboom 2 devices in TWS mode. Setp1 shows selecting a master and auxiliary. Setp2 shows power on. Setp3 shows pairing. Setp4 shows connection to a PC or tablet. Setp5 shows the final TWS connection.

Waterproof

A diagram showing the device is waterproof. It includes a red 'X' over a diagram of the device being submerged in water, and a diagram of the device being used in the rain.

Specification:

Bluetooth Version	V5.3	Wireless Transmission Distance	up to 33 ft (10M)
Maximum Output	25W	Charging Time	about 2.5 hours
Built-in Power	Li-ion 2500mAh	Playback Time	up to 12H Playtime (50% volume)
SNR	75dB	Charging	DC 5 V±0.5/2A
Wireless Working Frequency	80HZ-20KHZ	Size	(Dia.) 73mm*(H) 191mm

1. This logo means that no naked flames, such as a candle can be placed on or near the device.

2. The electrical and electronic equipment are part of a separate collection. Do not throw electrical or electronic equipment away with unsorted municipal waste, but ensure that it is collected separately. Collection systems and locations (sorting centres, rubbish dumps) are provided for your by local councils and retailers. By entrusting your end-of-life product to the proper recycling process, you can helping to protect the environment and your health.

3. Use this device in temperate climates only.

4. This device may be used by children aged 8 years or older any by those with reduced physical, sensory or mental abilities, or those lacking experience or knowledge, provided they are correctly supervised, or if the instructions related to the use of the device have been adequately given and if the risks involved have been understood. Children must not play with this device. Children should not clean or maintain the device without supervision.

5. The electrical socket must remain easily accessible if it serves as the means of disconnection.

6. Always unplug the device before cleaning it.

7. Clean the device with a soft dry cloth only. Never use solvents.

8. Attention should be drawn to the environmental aspects of battery disposal.

9. The battery (batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.

10. Use the apparatus in moderate climate only.

Bluetooth

Copyright 2021 SOWO Inc. All rights reserved. Bluetooth is a registered trademark of Bluetooth SIG, Inc. SOWO products are registered trademark of SOWO in the US.

Service contact: service@sowosound.com

Official website: www.sowosound.com

FC CE RoHS

FCC ID: 2APCP-Q18