

Hi, have a nice day!


Pls kindly follow below.

First of all, pls delete the extra cameras in the parent unit's system. If the camera with *, it means the camera has been added. pls delete the camera 2*, camera 3* and camera 4*, only leave/keeping the camera 1*.


1. press "OK" button, back to the main menu.




2. In the main menu interface, to find "camera" , pls delete the camera 2*, camera 3* and camera 4*, only leave/keeping the camera 1*.







3. After completing the above operation, you have successfully deleted an extra camera,if you have camera 3* and camera 4*,Also delete them as above way, only leave/keeping the camera 1*. Then press “OK” button again, back to the main menu, the extra cameras have been deleted,you will get the interface like below.



Secondly, pls pair the camera 1* again

1. Press the MENU  button then the main menu will show up, In the main menu interface, to find “camera” , then press ▲ button or ▼ button to select the camera 1*



2. Press  button to enter into sub-menu;

Press ▲ button or ▼ button to select ADD CAM  then press  button



3. The ... will be showed on the LCD screen.



4. Pull off plug from the back of baby unit/camera.



5. Press and hold(keeping) the PAIR button.




6. Re-plug the plug into DC jack. Don' t release the PAIR button before re-plugging plug.



7. Release the PAIR button after you have re-plugged the plug



8. .Once paired, “” will be showed on the LCD screen



To finish these two steps, your problem may be solved. hope that will help you, Thanks:)