



4" PORTABLE RECHARGEABLE FAN

USER MANUAL



*Subject to registering your extended guarantee online, please refer to the Instruction Manual for further guidance.

READING AND STORING THE USER MANUAL



Before using this product, please read through this manual carefully paying particular attention to the safety instructions. Failure to do so may result in personal injury or damage to the product.

Carefully save this instruction manual for future reference. Ensure the user manual is included when passing the product on to any third parties.

IMPORTANT SAFETY INSTRUCTIONS FOR PROPER USE

When using electrical appliances, basic safety precautions should always be followed.

Only use the product as described in this user manual. Any other use is considered improper and may result in damage to property or persons. The manufacturer or vendor cannot be held liable for damages or injury incurred through improper or incorrect use.

- **Read and familiarise yourself with all operating instructions before using this Table Mini Fan.**
- Before using your Table Mini Fan, visually check that the unit is intact and has not suffered any transit damage.
- Always use this appliance on a solid, level, non-flammable surface.
- Ensure that there is clearance of at least 100mm (4 Inches) minimum around the Table Mini Fan for sufficient ventilation.
- Ensure that any ventilation openings are not covered with items, such as newspapers, table-cloths, curtains, etc.
- No naked flame sources, such as lighted candles, should be placed on the Table Mini Fan.
- **DO NOT** position the Table Mini Fan close to sources of heat such as radiators, heaters, other electronic equipment, etc.
- The Table Mini Fan shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- **DO NOT** immerse the Table Mini Fan or its charging cable in water or any other liquids.

- **DO NOT** leave the Table Mini Fan unattended during use.
 - **DO NOT** leave the Table Mini Fan unattended whilst connected to a USB supply.
 - Close supervision is required when using this Table Mini Fan near children.
 - Never leave this Table Mini Fan within reach of children.
 - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
 - Children of less than 3 years should be kept away unless continuously supervised.
 - It is imperative to unplug the USB supply after the Table Mini Fan has been used, before it is cleaned and whilst being repaired.
 - Unplug after each use.
 - Repairs to electrical appliances should only be performed by qualified personnel. Improper repairs may place the user at serious risk.
 - **DO NOT** operate this appliance after a malfunction or after being dropped or damaged in any way.
 - **DO NOT** allow the charging cable to hang over sharp edges or come in contact with hot surfaces.
 - **DO NOT** run the charging cable under carpets, rugs, etc.
 - This product is intended for household use only and should not be used for industrial purposes.
 - **DO NOT** use any accessories or attachments with this product other than those supplied or recommended by supplier.
 - **DO NOT** use this product for anything other than its intended use.
-

- **DO NOT** push objects into any openings as damage to the product and/or electric shock may occur.

Explanation of Symbols

The following warning symbols or words are used in this instruction manual:



Products labelled with UK Conformity Assessment identifies products conforming to UK statutory requirements.




Products labelled with this symbol conform to applicable provisions of the European Economic Area.




This symbol provides useful additional information on the use of this product.



This symbol identifies voltage and the current rating for direct current.



This symbol means batteries and rechargeable batteries may not be disposed of with household waste!
As the end user you are required by law to bring all batteries and rechargeable batteries to a collection point run by the Local Authority or to a retailer, so that they can be disposed of in an environmentally friendly manner.



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk enter your postcode to find out your nearest recycling site.


Before the First Use of Your Table Mini Fan

Remove all packing materials and discard responsibly.

Ensure all parts are present (if applicable) see **Description of Parts** below.

Description of Parts

1. Fan Guard
2. Air Outlet
3. LED Indicator
4. Power / Speed Button
5. Air Inlet
6. USB charging Port
7. USB Charging Cable
8. Micro USB Plug
9. Large USB Plug

**Description of Parts - Accessories**

Charging the internal Battery

Before use, please ensure that the internal rechargeable battery is fully charged as follows:

1. Insert the **Micro USB Plug (8)** of the **USB Charging Cable (7)** into the **USB Charging Port (6)** on the rear panel of the Table Mini Fan to charge the internal battery.
2. Insert the **Large USB Plug (9)** of the **USB Charging Cable (7)** into a suitable USB charger rated at 1A or higher such as a dedicated USB mains charger or USB outlet on a computer.
3. The **LED Indicator (3)** will flash Red whilst charging. Once the battery is fully charged, the **LED Indicator (3)** will change to White to indicate fully charge and the **USB Charging Cable (7)** can be removed.
4. The internal battery can operate for 2 - 8hours after it is fully charged. Battery will take 2 - 3hours to fully charge from flat.



i The Table Mini Fan can be used whilst connected to the USB supply.

Using Your Table Mini Fan

1. Switch on the Table Mini Fan by pressing the **Power/Speed Button (4)**.
2. Press the **Power/Speed Button (4)** for fan speed I.
3. Repeatedly press the **Power/Speed Button (4)** for speeds 2 and 3.
4. The **LED Indicator (3)** will illuminate White when the Table Mini Fan is switched ON (speed I).
5. Further press the **Power/Speed Button (4)** after Speed III to switch the unit off.



i The airflow direction can be adjusted by swinging the **Fan Guard (1)** up and down.

i The **LED Indicator (3)** will flash Red whilst during use when the battery Power is less than 20%



Care and Use of your Table Mini Fan


- Always disconnect the Table Mini Fan from the USB supply before cleaning.
- Clean outside of the Table Mini Fan with a clean damp cloth. Never clean with harsh or abrasive cleaners.
- Do not submerge the Table Mini Fan or its charging cable in water or any other liquids.
- Keep the Table Mini Fan in dry place.

Technical Specification

Model Number	COL1540
Rated Power	4W
Charge Input	DC 5V 1A
Battery Type/Capacity*	Li-ion 3.7V 1800mAh
Unpacked Weight	Approx. 235g
Dimensions (Approx.)	167mm (H) x 85mm (W) x 118mm (D) Approx.

***Battery is not removable**

Disposal of the Packaging




Dispose of paper and cardboard in appropriate paper recycling facilities.


Dispose of plastics in the appropriate plastics collection service.

Dispose of non-recyclable plastics in the appropriate plastics collection service.

Disposal of the Product



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk enter your postcode to find out your nearest recycling site



This symbol means batteries and rechargeable batteries may not be disposed of with household waste!

As the end user you are required by law to bring all batteries and rechargeable batteries to a collection point run by the Local Authority or to a retailer, so that they can be disposed of in an environmentally friendly manner.





WARRANTY

Thank you for purchasing your Daewoo product.

As part of our commitment to quality, we are offering you an extra 2 years warranty in addition to your 1 year guarantee

Your Daewoo product is guaranteed for 1 year from the date of original purchase, with proof of purchase or receipt. If any defect should occur due to faulty workmanship or material, your faulty product should be returned to the place of purchase, replacement or refund is at the discretion of the retailer.

The guarantee is subject to the following provisions:

- The product must be correctly installed and operated in accordance with the requirements contained in the instruction manual.
- The product must be used solely for domestic purposes.
- It does not cover general wear and tear, damage, misuse or any consumable parts.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged through inexpert repair.
- The guarantee is only valid within the UK and Eire.

Your standard 1 year guarantee will only be extended to the maximum available for your individual product upon registration. (Note: products must be registered individually and covers the main body and housing). If you do not register your product within 28 days of the original purchase date, your product will only be guaranteed for 1 year.

To validate your extended 2 year warranty*please register your purchase online within 28 days of the original purchase date by registering at:

<https://help.daewooelectricals.com>

or

[Contact Us \(daewooelectricals.com\)](https://help.daewooelectricals.com)

***Your extended warranty is only valid with proof of purchase receipt and subject to the conditions outlined above.**

Daewoo is a registered trademark.
Produced and imported under licence by
ESG Ltd. Manchester M3 1JS UK
EU Rep: EuroSonic Magppie (ESM) Ltd. Ireland D05 X006
www.esgltd.com