

LONICERA

User Instruction

Features :

- Measurement range : -50°C ~ 300°C (-58°F to 572°F)
- Display Resolution : ± 0.1
- Measurement accuracy : $\pm 1^{\circ}\text{C}$ (2°F) at -20°C ~ 150°C (-4°F ~ 302°F)
- IP66 Waterproof
- "Hold" function
- °F/°C switchable
- Backlight on/off
- Auto off after 10 Min. of inactivity

Operation:

1. Before use, please remove the protected film from the front panel.
2. Press  to turn the unit on. To turn off, press the  button again.
3. Probe is set to read temperatures in Fahrenheit . To switch to Celsius, press and hold the  button for 2s.
4. To test temperature, insert probe into thickest part of food.
5. Data-hold. Before withdrawing from food, press **HOLD** button. This will "hold" the temperature reading until pressed again.
6. To light the LCD ,please press the  button once ,press it again to turn off . Also the backlight will auto off after 10s of inactivity .
7. To change the battery, use a coin to open the battery compartment on the back, The type of battery used must be a 3V CR2032.

Warnings and precautions!

DO NOT LEAVE THE THERMOMETER IN THE OVEN WHILE COOKING.

DO NOT TOUCH HOT PROBE WITH BARE HANDS.

Wash the metal probe in soapy water.

Clean the thermometer by wet washcloth or running water.

Do not completely immerse the digital thermometer in water .

Sterilize the metal probe by inserting it into boiling water for several minutes.