



DREVO 84K

Mechanical Keyboard

User Manual

COMBINATION KEYS

FN+F1	THIS PC	FN+F7	Play/Pause
FN+F2	Browser	FN+F8	Stop
FN+F3	Calculator	FN+F9	Mute
FN+F4	Media Player	FN+F10	Volume Down
FN+F5	Previous Track	FN+F11	Volume Up
FN+F6	Next Track	FN+F12	Windows Key Lock

KEYBOARD SET

FN+ `~	Keyboard Lock	FN+ESC+F1 +F3+F5	Keyboard Reset
--------	---------------	---------------------	----------------

You can press FN+`~ to lock/unlock the keyboard and FN+ESC+F1+F3+F5 to reset the keyboard.

FN+DEL	Insert	FN+PAU	Scroll Lock
FN+PS	Numpad Activate		

BACKLIT EFFECT

FN+ ↑	Backlit Brightness+	FN+ ↓	Backlit Brightness-
-------	------------------------	-------	------------------------

FN+←	Switch Backlit Mode	FN+→	Breathing Effect ON/OFF
------	------------------------	------	----------------------------

SELF-CUSTOMIZED LIGHT SOLUTION

FN+1!	Switch among Self-Customized Lighting Solutions
FN+2~6	Self-Customized Light Solutions

e.g. Press FN+2 to activate the recording mode (Key "2" blinking); Choose the keys you preferred to customize; Press FN+2 to save the customization. Similarly, you can FN+3/4/5/6 to customize another 4 light solutions, and you can switch among them free by press FN+1! .

****NOTE**** The LEDs of F12, PS, PAU and CAPSLOCK are off by default in every backlit effect. But once you activate the function of WinsLock, NumLock ScrollLock or CapsLock, the relevant LED will light on all the time.