

Setup Guide

Téléviseur
Televisor
Televisor digital a color con pantalla de cristal líquido

5-024-944-12(1)

US	Setup Guide
FR	Manuel de configuration
ES	Guía de configuración
PT	Guia de Configuração

Sony Customer Support

U.S.A.:
<https://www.sony.com/tvsupport>
Canada:
<https://www.sony.ca/support>
United States 1.800.222.SONY
Canada 1.877.899.SONY
Please Do Not Return the Product to the Store

Service à la clientèle Sony

Canada:
<https://www.sony.ca/support>
États-Unis:
<https://www.sony.com/tvsupport>
Canada 1.877.899.SONY
États-Unis 1.800.222.SONY
Ne retournez pas le produit au magasin

Lea este manual antes de usar el producto

Centro de Asistencia de Sony



<https://esupport.sony.com/ES/LA/>
Llame al número telefónico que aparece en su póliza de garantía.
Por favor no devuelva el producto a la tienda donde adquirió el producto.

Suporte ao Cliente Sony



<https://www.sony.com.br/electronics/support>
Por favor, não devolva o produto à loja

BRAVIA



XR-75X90J / 75X90CJ
XR-65X90J / 65X90CJ
XR-55X90J / 55X90CJ





1





2





3





4




5



6



7




*1 Refer Reference Guide / Reportez-vous au Manuel de référence / Consulte la Guía de referencia / Consulte o manual de instruções


*2 Only on limited region/country/TV model. / Uniquement pour certaines régions/pays/modèles de téléviseurs. / Solo en regiones/países limitados/Modelo de TV. / Somente para determinadas regiões/países/modelos de TV.




8




9





10





11



12



Help / Aide / Ayuda / Ajuda



<https://www.sony.com/tvsupport>
<https://www.sony.ca/support>
<https://esupport.sony.com/ES/LA/>