


WE ARE

crua
OUTDOORS

Crua Culla/ Maxx

Instruction Guide



UNPACKING & SETTING UP YOUR NEW TENT


- Before inflating the Culla, place it inside the Crua Duo or any other water proof tent. Ensure the Culla door is aligned with the tent door.
- Starting from one end of the tent, unscrew the top cap of the inflation valve and attach the pump nozzle.
- Inflate each air pole until it's quite firm (7PSI if your pump has a gauge). Pump up each (2) airpole.
- It is normally necessary to adjust the tent and to push the poles upwards so that the airpoles can assume their correct shape.




- Once all the air poles have sprung outwards, assuming their correct shape, detach the pump from the tent and tighten the outer valve cap on each inflation point. It is important that these are tight to prevent the seepage of air.
- Please ensure there is proper ventilation at all times by utilizing the vents on your Culla tent. Please also make sure the vents are used on your exterior tent as well.

LIVE TOUGH! SLEEP EASY!

Take down
instructions



- Close all doors and openings.
- Open the valves on each pole. The tent will start to deflate. Wait until most of the air has been expelled.
- Fold both sides to meet in the middle and then fold one more time together. Roll again to fit in the bag.
- Always roll towards the door of the tent. This will help the air trapped in the tent or the air beams to be pushed out while it's being rolled up. Leave valves open while not in use.
- Use compression straps provided to further deflate the air from insulation and reduce the bulk.
- Ensure that the tent is totally dry before storing in a cool dry, dark space (If possible opened out).



"Through a 6-hour thunderstorm complete with 35mph winds- no leaks, no issues whatsoever."

- Rod M on Dec 04, 2019