

TO OPERATE:

- Once the unit is fully assembled, load balls into the ball feeder.
- Slide the power switch to "ON" position.
- Once the machine turns on and the motor reaches its operating speed, a ball will drop into the chute. The red light will come on immediately before each ball is passed out of the chute opening.

NOTE:

The first ball may not shoot at full speed and distance due to location on lever when machine is turned on.

- The remaining balls will drop into the machine as the cycle continues.
- The unit will shoot the balls approximately 8 seconds apart.
- The red light comes on immediately before each ball is passed out of the chute opening.
- After all loaded balls have been passed; the motor will shut off to conserve battery life. The red light will remain on until more balls are placed in the ball feeder or unit is switched to "OFF" position.

NOTE:

Be sure to turn power to "OFF" position when reloading balls in ball feeder. When the balls have been loaded into the ball feeder, make sure the player is ready, then slide the switch to "ON" position. The balls will automatically activate the motor if unit is in the "ON" position.


NOTE:

To conserve batteries remember to turn product to "OFF" position. Remove batteries when stored for long periods of time.

CAUTION:

Not to be used in wet conditions. Do not store outside.

BATTERY INSTALLATION:



Insert batteries into base unit as shown.

- Requires 4 "D" size batteries (not included)
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

Made In China
Franklin Sports Inc.
Stoughton, MA 02072

Franklin

For replacement parts:
Visit: www.franklinsports.com/14278
Email: parts@franklinsports.com
Call: 1-800-225-8649

Franklin



ONE TIMER HOCKEY PASSER

ITEM NUMBER: **14278**



NOTE: PRINT FRONT TO BACK

PARTS LIST


1  Base Unit QTY x1	2  Ball Feeder QTY x1
3  Hockey Balls QTY x4	

IMPORTANT


- This product is intended only for outdoor recreational use.
- Use only with 2 5/8" street hockey balls. Do not attempt to use any other balls. (All Franklin street hockey balls are 2 5/8" and will work with this product).
- Do not place hands or objects into any opening of the machine while in the "ON" position. Injury or damage may occur.
- Do not stand in front of players using this machine unless wearing proper hockey gear protective equipment including a helmet with face mask.
- Do not point toward or use near breakable objects. For example: glass windows and doors.
- If the product jams, turn machine to "OFF" position. Lift up and turn toward ground or upside down to dislodge ball. Do not point toward any person.
- Use only on a flat playing surface.
- Adult assembly and supervision is recommended.

ASSEMBLY INSTRUCTIONS

STEP 1



PARTS



NOTE

Slide the **Ball Feeder (2)** into place on the **Base Unit (1)** as shown.

Load the **Hockey Balls (3)** into the ball feeder.

YOU ARE NOW READY TO PLAY!