


Srhythm


Find the rhythm of your soul

Quick Start Guide (NC25/NC35)




Bluetooth :  3s



1

OTHER DEVICES 


Srhythm NC25

OTHER DEVICES 



Srhythm NC35





2



◻ × 1 : ▶ / ⏸ / ↶ / ↷




ANC 2s : 




◀ ×1: 🔊 -


◀ 2s: ⏪



▶ ×1: 🔊 +

▶ 2s: ⏩







Downloadable manual

Herunterladbares Handbuch

Manuale scaricabile

Manuel téléchargeable

Manual descargable

取扱説明書のダウンロード

다운로드 가능한 매뉴얼

Manual para download

מדריך להרודה



Scan to Download

<https://www.srhythm.com/pages/drivers-manuals>



If any part of your product is damaged, do not use it. Contact your authorized Srhythm dealer or Srhythm customer services.

Wenn ein Teil Ihres Produkts beschädigt ist, verwenden Sie es nicht. Wenden Sie sich an Ihren autorisierten Srhythm-Händler oder den Srhythm-Kundendienst.

In caso una qualsiasi delle componenti del prodotto fosse danneggiata, non utilizzarla. Contattare il rivenditore autorizzato Srhythm o il servizio clienti Srhythm.

Si une partie de votre produit est endommagée, ne l'utilisez pas. Contactez votre revendeur Srhythm agréé ou le service client Srhythm.

製品の一部が損傷している場合は、使用しないでください。Srhythmの正規販売店またはSrhythmカスタマーサービスに連絡してください。

제품의 일부분이 훼손된 것을 확인한 경우, 사용하지 마십시오. 정식 Srhythm 고객 서비스, 혹은 정식 Srhythm 딜러에게 연락하십시오.

Se alguma das partes do seu produto estiver danificada não o utilize. Entre em contato com seu revendedor autorizado da Srhythm ou com o atendimento ao cliente da Srhythm.

אם חלק כלשהו במוצר שלכם פגום, אל תשתמשו בו. פנו למשווק המורשה או לשירות הלקוחות של Srhythm.