

Oraolo

M91  
IPX5 WATERPROOF  
WIRELESS SPEAKER



USER MANUAL

# CONTENTS

---

WHAT'S INCLUDED	1
PRODUCT FEATURES	1
DIAGRAM OF CONTROLS	2
TECHNOLOGY SPECIFICATION	3
CHARGING WIRELESS SPEAKER	4
WIRELESS MODE	5
WIRELESS PAIRING DIAGRAM	6
AUX-IN MODE	7
TF CARD MODE	8
CARE AND MAINTENANCE	9
LIMITED WARRANTY	10

## WHAT'S INCLUDED

---

- M91 ----- 1pc
- User manual ----- 1pc
- Aux-in Cable ----- 1pc
- Micro USB Charging cable ----- 1pc

## PRODUCT FEATURES

---

- Water resistant IPX5 & Ultra-portable with TPU handle
- High quality crystal clear sound
- Louder volume & more bass
- Latest wireless technology
- Long battery & Lifetime guarantee
- Support WIRELESS/Aux-in/TF card mode


# DIAGRAM OF CONTROLS

---

Volume + / Next Track

Long press: next track  
Short press: volume up


Wireless pairing: Long press  
Mode Switch: Short press



Turn on/off: Long press  
Short press: Play/Pause  
Short press:  
Answer calls/Refuse calls

Volume - / Last Track

Long press: last track  
Short press: volume down



## TECHNOLOGY SPECIFICATION

---

- Model No: M91
- Speaker driver: 4Ω
- Sensitivity: 82 ± 2dB
- Output power: 12Wx2
- Speaker unit size: 3"x2
- Charging Time: about 4-5 hours
- Product size: 278x119x125mm

## CHARGING SPEAKER

---


### NOTE:

Before using M91, please use the micro USB cable (included in the package) charging.

(1).The speaker must be turned off before charging, to avoid making the speaker work abnormal, please do not charge when the unit is power on.

(2). Plug the small micro USB pin into the charger port on the rear side of speaker, and the another end of the cable (the standard USB 2.0 plug) into any standard USB port (such as a computer or USB charger).

(3). The red LED will automatically turn on while it's charging, when fully the charged, the LED indicator light will be turned off.



## WIRELESS MODE

---

1. Long press and hold "▶🔊" to turn speaker on;
2. M91 is ready to pairing, the LED indicator will be flashing white, Usually set the steps to enter the "Settings" - > "M91";
3. Once paired successfully, the power indicator turns blue and makes a prompt sound.
4. When incoming call, Short press"▶🔊" button to answer. Hang up, please press "▶🔊"again .

### Note:

(1). If the speaker is in low power or in weak state, sometimes it may not be connected to the phone, PC, IPAD or other devices. please charging immediately before using.

(2). When the enable audio device is connected, if it exceeds the connection distance over 10M, the signal will be disconnected. when you closing the speaker, it will automatically be reconnected.

# WIRELESS PAIRING DIAGRAM

---




## AUX-IN MODE

---

(1). Connect with a 3.5mm cable for Aux-in mode playing, the LED indicator to be Red.

(2). In AUX-IN mode, can not answer the incoming calls via M91 speaker.

Note: When AUX-IN jack is connected it will be automatically turn on AUX-IN mode. But Short press " M " is switch mode to wireless.




## TF CARD MODE

---

(1). To insert a TF card into the unit, you can play music from it.

(2). In TF card mode, you can not answer the incoming calls via M91 speaker.

Note: When the TF card is inserted, it will automatically turn on TF card mode. But short press “M” is to switch to Wireless mode.



## CARE AND MAINTENANCE

---

1. Long press"  " 2 seconds to turn off the device, to make sure that it is properly protected.



2. Avoid high temperatures (above 40 degrees Celsius), for example, in hot cars or direct sunlight.



High temperature will be damage the surface and reduce battery life.

## LIMITED WARRANTY

---

The warrants of Oraolo products that it will furnish a replacement or repair any part which proves (upon inspection by Oraolo) to be defective under normal use within 18 months of the original purchase date.

This warranty does not apply to appearance items, accessories in the human damage caused by leaking batteries. It also does not apply to the product, or to any part thereof, that has been damaged through misuse or negligence.

Furthermore, this warranty will become invalid, in the judgment of Oraolo products or any parts has been installed incorrectly, repaired or altered by other than Oraolo Service department.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation incidental or consequential damages or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

For Service, Warranty, or Product Information,

Please contact : [oraolo\\_eddie@126.com](mailto:oraolo_eddie@126.com)

PLEASE SAVE THIS CARD TOGETHER WITH ORIGINAL DATED PROOF OF PURCHASE FOR YOUR RECORDS AND FOR CUSTOMER SERVICE.