Care and Maintenance

- Keep the facial exfoliator cover on when handling the unit. Uncover when you are ready to use.
- For best results, dispose of Finishing Touch Flawless® Dermaplane Glow head after each use.
- Make sure unit is turned off after use.
- Do not submerge unit in water, or any other liquid.
- Store unit in a dry, safe place.

Warning

- DO NOT USE Finishing Touch Flawless® Dermaplane Glow unit on unintended areas of the body (including lips, nose and directly over the eyelids). Flawless Finishing Touch Flawless® Dermaplane Glow is designed for use ONLY on the forehead, above the upper brow, cheeks, upper lip are and chin.
- DO NOT USE Finishing Touch Flawless® Dermaplane Glow unit on skin that is experiencing dryness, acne, sunburn, psoriasis, eczema, diabetes, circulatory or bleeding disorders, or on skin that has just been medically treated. Discontinue use if skin irritation occurs.
- DO NOT USE on moles, sores, or lesions.
- DO NOT rinse handle or unit under water, or submerge in liquid.
- DO NOT dispose of battery by incinerator or fire.
- Dispose of old batteries according to all applicable local regulations.
- Not intended for persons 12 years of age or under.

Church & Dwight UK Ltd.,
Folkestone, Kent, CT19 6PG
Tel: 0800 130 3448

SOFIBEL SAS - 92686
Levallois-Perret
Cedex-France

8Made in ChinaUKFTFGLOIM040320MW

FINISHING TOUCH

FLAWLESS® DERMAPLANE GLOW

Lighted Facial Exfoliator



• EXFOLIATES • REMOVES • SMOOTHES

REPLACEMENT HEADS INCLUDED


Lighted Facial ExfoliatorFacial Massage and Contouring Kit



Use a new Finishing Touch Flawless® Dermaplane Glow head for each use.

- Press the top of the handle down into the top of the new head. (Image 7C).

Image 7D



- Rock the handle backward, being sure to press down until you hear the new head click into place. (Image 7D).

Image 7E

- The unit is now ready for use (Image 7E).

NOTE: DO NOT USE if replacement head appears to be damaged.

2 **7**

- Be sure the unit light is off.

Replacement Heads

- Remove the head by sliding the ejection button down (Image 6).





Image 6

- Discard the old head.
- Hold the tray securely with one hand. With the other hand, grasp the handle.


Image 7A

- Hold the top of the handle over a new head (Image 7A).
- Angle the top of the handle down toward the top of a new head (Image 7B).


Image 7B

PRIOR TO FIRST USE

- **Test on a small, discreet area.**
- **Discontinue use immediately if sensitivity or allergic reaction occurs**.


Getting Started

Finishing Touch Flawless® Dermaplane Glow comes ready to use right out of the package.

Recommended for exfoliation/hair removal on the forehead, above the upper brow, cheeks, upper lip area and chin.

INSERT / REMOVE BATTERY

- Gently pull off the battery cap to reveal battery compartment (Image 1).
- Place 1 AAA battery into the compartment, making sure the positive pole (+) is facing the top of the unit.
- Push the cap back securely onto the handle.
- Repeat for battery replacement.


Image 1

How to Use

6 3

DRY

at night, before bed, to give skin time to recover.

Be sure to space treatments 2 to 4 weeks apart.

- Select a new, clean head for each use.
- With one hand holding the handle, gently slide the cover off with the other hand (Image 2).




Image 2

- Press ON button to illuminate area (Image 3).
- For best results, hold the skin taut with your free hand and the unit at a 45º angle with the other.




Image 3

- Use short, feathery strokes and gently skim across skin, beginning at the hairline and moving inward following the contours of the face (Image 4).
- Do NOT press the head down into the skin. No pressure should be used. Pass over the same area only ONCE during each use.



Image 4

- It is recommended to use the Finishing Touch Flawless® Dermaplane Glow in the pattern suggested. (Image 5).




Image 5

USE ONLY.

It is recommended to dermaplane

PRO TIPS

- After dermaplaning, let your skin rest.
- Do not use creams or make-up for several hours afterward.

AFTER USE

- Allow skin to breathe for several hours before applying lotions, serums or make-up.
- Applying make-up immediately after using is NOT recommended.

- Do not sunbathe directly after use.

Note: After use, skin may be slightly pink or red. This is normal after treatment and should fade within a few hours.

If redness or burning increases over time, discontinue use of product.

MORRIS/WEBER ADVERTISING
75 Lane Road
Fairfield, NJ 07004
973-478-2300

Job Title/File Name: **FT Flawless GLO_UK_IM_8 Page_09**

Client: **Ideavillage** Requested by: **Erica Pisano**

Dated Submitted: **4/3/20** Size: **8.5x11**

Color: ☑ 4/C ☐ BW ☐☐☐☐ Spot Color

Version #:

Approved by: ~~sonia De Vito~~ Date: ~~20.4.20~~