


88 5008 941 Monarch Kitchen Island

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.


We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.




Home
Styles

Patent 8,584,600 B2

Part List



Hardware List



For assembly also need the following:

88 5008 942 Monarch Kitchen Island Carton quantity: 1	88 5008 943 Monarch Kitchen Island with Oak Top or 88 5009 943 Monarch Kitchen Island with Granite Top Carton quantity: 1
 P. Frame Leg 1 pc. Q. Frame Leg 1 pc.	 A1. Top 1 pc. A2. Top 1 pc. 3/4" Flat Head Screw 12 pcs. (+1 extra)

Tools Required For Assembly : Phillips screwdriver

Tools recommended for assembly: Level

Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319

servicedesk@homestyles-furniture.com

Revised date : 27 Nov 2013

Assembly Instructions 2/8

IMPORTANT

- * Please keep Hex Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.
- * Do not tighten up all the screws until each part is properly assembled.
- * Use a soft cloth between these parts and the floor.
- * After assembly, item must be level to work properly. Use the included adjustable levelers to level.





Figure 1





Assembly Instructions 3/8

STEP 3

Slide Back Panel (K) into the groove of Back Rail (G) and (H) and Back Piece (L).

Attach Middle Panel (D) to Front Rail (E) and (F), Back Rail (G) and (H) and Back Piece (L) using Cam Locks. (See figure 2)



STEP 4

Attach Side Panels (B) and (C) to unit using Cam Locks.

Assembly Instructions 4/8

STEP 5

Attach Bottom (J) to unit using Cam Locks, Head Cap Bolts (long) and Washers.

Tighten bolts using Hex Wrench.
(See figure 3)






Figure 3



STEP 6

Attach Frame Leg (P) and (Q) to unit using Head Cap Bolts (short).

Tighten bolts using Hex Wrench.

STEP 7

Attach Doors (M) and (N) to the side panels, by sliding the door lift hinges into the side panel lift hinges.
(see Figure 4)

Assemble Pull Handles to Door (M) and (N) with Machine Screws.
(see Figure 5)




Figure 4





Figure 5




STEP 8

Slide Drawers (O) into place.


Insert Adjustable Pins into side panels and middle panel at the desired level.

Slide Shelves (I) into position.



Assembly Instructions 6/8

STEP 9



Attach Top (A1) to Top (A2) using 3/4" Flat Head Screws (Hardware included in carton 88 5008 943 for Wood Top or 88 5009 943 for Granite Top).

STEP 10

Pull out the Drawers from unit.

Place Top (A) onto the unit, using Head Cap Bolts (long) and Washers.

Tighten bolts using Hex Wrench.
(see Figure 6)

Side Drawers into place.






Figure 6


STEP 11

To level the unit, adjust the adjustable levelers on the bottom.



Assembly Instructions 7/8

STEP 12



When Leaf Top is down, it should be oriented vertically.

If it is not vertical and adjustment is desired, loosen the Head Cap Bolts (short) which attach Top (A) to the unit.



Slide Top (A) slightly forward or backward until the Leaf Top is oriented vertically.

Re-tighten the Head Cap Bolts. (See Figure 6)

TOP EXTENSION INSTRUCTIONS

STEP 1


Lift up the Leaf Top.



STEP 2

Holding the Leaf Top up, pull out a back leg from the unit; then pull out the other back leg.

Drawer (O)





STEP 1

Attach Side Part (O3) to Front Part (O1) and Back Part (O2) using a Phillips screwdriver and 1 1/4" Flat Head Screws.

STEP 2

Insert Base Part (O5) into the groove.






Attach Side Part (O4) to Front Part (O1) and Back Part (O2) using a Phillips screwdriver and 1 1/4" Flat Head Screws.



STEP 3

Attach Pull Handles with Machine Screws.

Part List



VERY IMPORTANT !!

CARE INSTRUCTIONS

NEVER

USE GLASS CLEANERS ON FINISHED FURNITURE. AMMONIA WILL CHEMICALLY ATTACK THE LACQUER.

NEVER

ALLOW LIQUIDS OF ANY KIND TO REMAIN ON THE FURNITURE. ABSORPTION CAUSES WOOD TO WARP AND SPLIT AND FINISHES TO DELAMINATE.

DO NOT
WRITE
DIRECTLY
ON
SURFACE.




**PREVENT
MARKING**

DO NOT
PLACE IN
DIRECT
SUNLIGHT.



**PREVENT
FADING**

DO NOT USE
COMMERCIAL
WAXES AND
POLISHES.



**PREVENT
YELLOWING**

DO NOT
PLACE HOT
OBJECTS
ON SURFACE.



**PREVENT
FINISH DAMAGE**

DO NOT
USE
RUBBER
BASED
PLACE MATS.



**PREVENT
DISCOLORING**

TO CLEAN

USE A SOFT CLOTH MOISTENED IN LEMON OIL POLISH OR LUKEWARM SOAP AND WATER, THEN BUFF WITH A DRY CLEAN CLOTH.



88 5008 942


Monarch Kitchen Island

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.


We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

*Home
Styles*




Patent 8,584,600 B2

Part List



P.
Frame Leg
1 pc.



Q.
Frame Leg
1 pc.

For assembly see instructions in carton 88 5008 941

Home Styles Consumer Assistance: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319

88 5008 943


Monarch Kitchen Island with Wood Top

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.


We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

*Home
Styles*



Patent 8,584,600 B2

Part List



A1.
Top
1 pc.

A2.
Top
1 pc.

Hardware List



3/4" Flat Head Screw
12 pcs. (+1 extra)

**For assembly see instructions in carton
88 5008 941 or 88 5020 941**

Home Styles Consumer Assistance: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319