V20210252

Barber Chair
User Manual



Read Carefully Before Use
Keep for Future Reference

Safety Information

⚠ Warning!

- **ALWAYS** ensure all fasteners and components are intact and securely tightened before each use.
- **DO NOT** use this chair if it is damaged or malfunctions. Repair or replace worn or broken parts before further use.
- **DO NOT** load this chair with more than 200 kg (440 pounds).
- **DO NOT** leave children or persons with compromised physical or mental capabilities using this chair without close supervision.
- Store this product out of the reach of children after use.

Product Diagram



Package List

No.	Part	Qty.
1	Seat	1
2	Backrest	1
3	Footrest	1
4	Hydraulic Pump	1
5	Pedal	1
6	Base	1
7	M5×25 Bolts	6
8	M5×20 Bolts	6
9	Washers	2
10	Caps	4
11	5mm Allen Key	1
12	4mm Allen Key	1

Specifications

Height Range	84–94 cm (33–37 in.)
Seat Area	50 × 50 cm. (20 × 20 in)
Weight Capacity	200 kg (440 lb.)
Net Weight	22 kg (48.5 lb.)

Assembly

1. Place the hydraulic pump onto the base, aligning its bottom holes with those of the base. Secure the pump using the M5×20 bolts and tighten them with the 5mm allen key.




2. Loosen the pre-installed set screws on the pump using the 4mm allen key. Fit the pedal onto the pump and secure it by retightening the screws.



3. Place the backrest between the armrests, aligning its holes with those in the connecting plates of the armrests. Secure the backrest using four M5×25 bolts and tighten them with the 5mm allen key. Attach the provided caps to the bolts and press them into place.



4. Fit the footrest onto the bottom of the seat. Secure it using the remaining two M5×25 bolts together with the washers. Tighten the bolts with the 5mm allen key.



5. Insert the top of the hydraulic pump into the central hole underneath the seat. Place the chair on a level surface and press down on both armrests until the seat is secure.

Adjustment

To raise the chair, press the pedal lightly, quickly and repeatedly until your desired height is reached.

To lower the chair, hold the pedal while someone is sitting in it or while pushing down on it.

Maintenance

- The exterior of this chair should be cleaned periodically with a soft damp cloth. Do not use abrasive cleaners or caustic chemicals.
- Check the parts for any looseness, wear, or damage after prolonged use. Tighten, repair, or replace any problematic parts before further use.
- If this chair will not be used for a long period of time, store it in a cool, dry, and safe place.

Contact Us

Thank you for choosing our products! If you have any questions or comments, contact us at **help@cs-supportpro.com** and we'll resolve your issue ASAP!

For a .pdf copy of the latest version of these instructions, use the appropriate app on your smartphone to scan the QR code to the right.