


D10使用说明书




使用产品前请仔细阅读产品使用手册，并妥善保管
好以便日后查阅

一、产品特点介绍


- 1、独特的工业外观，防摔、防撞、牢固耐用；
- 2、超大的电池容量，自用模式下还可 USB 充电输出；
- 3、双风叶设计，增大风量；
- 4、风扇自带的强力 LED 灯照明，亮度 3 档调节；
- 5、此产品除了平台摆放工作以外，还可多场景倒挂旋转使用；
- 6、打开夜晚模式，可关闭风扇的指示灯，睡觉不刺眼。

二、产品结构



三、使用方法

按键控制区：



- 1、短按 “ ” 开关键，风扇依次在《1档、2档、3档、4档、关闭》5种状态中切换，长按开关键1档、2档、3档、关闭》4种状态中切换，长按开关键关闭；
 - 2、短按 “ ” 开关键，LED 灯依次在《1档、2档、3档、关闭》4种状态中切换，长按开关键关闭；
 - 3、睡眠功能：工作状态下短按 “ ” 开关键，依次在《开启、关闭》2种状态中切换；
- 注：开启睡眠功能即是关闭所有指示灯，关闭睡眠功能或者输入 / 输出时指示灯会再次打开。

四、充电说明/移动电源功能



- 1、充电时间：8-9 小时（用 5V-3A 充电器测试，使用 低于 5V-3A 的充电设备，充电时间会因此稍长）
 - 2、接入 DC-5V 电源，系统自动打开充电功能，充电过程中控制面板的电量指示灯相应的电量灯闪烁，充满电后电量指示灯 4 个常亮。
 - 3、移动电源功能：用充电线连接通外部设备即可，在与外部设备连接时，一定要选用与之对应参数范围内的功率，否则会对设备造成损害。
- 注：1、充电线请使用原装线（3A 快充线），用普通充电线充电时间会因此稍长
- 2、由于设备之间的充电协议问题，部分手机可能不兼容 TYPE-C 输出

产品规格	
产品名称	充电风扇
产品型号	D10
产品尺寸	219x102x258mm
电池容量	20000mAh
额定功率	15W
TYPE-C输入	5V-3A
TYPE-C输出	5V-3A
USB输出	5V-2A
续航时间	风扇：1档≈72H，2档≈48H，3档≈25H，4档≈18H LED灯：1档≈100H，2档≈36H，3档≈18H 风扇与LED灯最大档≈9H

五、安全注意事项

1. 请勿将本产品置于暴晒或者高温、火烤等环境；
 2. 请勿将本产品置于潮湿的地方；
 3. 严禁将本产品投入或者接近火源，以避免发生火灾等；
 4. 禁止拆卸、打开、切割、或者刺穿本产品；
 5. 产品使用过程中，如发生异常情况，请立即停止使用；
 6. 长时间不使用产品时，需要每隔 2-3 个月给产品充电 1 次，
- 充电的时候，因为长时间搁置会导致电池电量损耗，无法再次充电。

六、保修说明

本公司承诺自购买公司产品之日起 3 个月内，若发生质量上的问题(不可抗力除外)将予以免费维修或更换。自购买之日起超过 3 个月后，需付费维修或更换。请仔细阅读保修卡内容，并妥善保管。

下列情况不在免费保修范围之内：

- 易耗品

- 因使用错误或擅自修理及改造导致的故障和损伤
- 因购买后运输、移动、掉落、撞击等导致的故障和损伤
- 因火灾、地震、消灭、打雷等不可抗力导致的故障和损伤
- 未按照说明书注意事项要求使用情况下导致的故障和损伤

保修卡：


1. 整机保修期为 3 个月；
2. 发票和保修卡做为保修凭证，请妥善保管；发票一经涂改，保修失效；
3. 非产品自身质量问题造成的损坏和故障，将收取维修服务费；

顾客姓名：_____ 联系电话：_____

产品型号：_____ 购买日期：_____



D10 User Manual




Please read the user manual carefully before using, and keep it properly for future reference.

1. Product Features


- 1) Unique appearance, shatter resistance, anticollision, sturdy & durable;
- 2) Super-large capacity battery, the fan can be used as a power supply to charge other devices via the USB port;
- 3) 2 triblades increase the air flow;
- 4) It is equipped with powerful LED lighting, 3 brightness settings;
- 5) It can not only be used on workbench, but also hanged upside down and used in many occasions;
- 6) Turn on the sleep mode, the battery indicators and fan speed indicators will be off without disturbing your sleep.

2. Product Structure




3. How to Use

Control Panel:



- 1) Short press “ ” button, the fan will switch among 1/2/3/4/OFF; long press this button to turn the fan off.
 - 2) Short press “ ” button, the LED lights will switch among 1/2/3/OFF; long press this button to turn the LED lights off.
 - 3) Sleep mode: short press “ ” button to turn ON/OFF the battery indicators and fan speed indicators.
- Please note: Sleep mode is to turn off the indicators. When restart the fan / LED lights or input / output current, the indicators will be on again.

4. Charging / Power Bank Function



- 1) Charging time: 8-9 hours (tested with 5V-3A charger. If you use a charger that lower than 5V-3A, the charging time will be a bit longer.)
 - 2) Connect with DC-5V power supply, it will start to charge the device. During charging, the corresponding battery indicator will flash; the 4 battery indicators will be steady on after fully charged.
 - 3) Power bank function: it can charge other devices via charging cord. When connecting with other devices, please pay attention to the power to make sure that the power is within the range, otherwise it will cause damage to the device.
- Please note: Type-C output port is NOT compatible with some mobile phones.

Specifications	
Product Name	Rechargeable Fan
Product Model	D10
Product Size	219x102x258mm
Battery Capacity	20000mAh
Rated Power	15W
TYPE-C Input	5V-3A
TYPE-C Output	5V-3A
USB Output	5V-2A
Battery Life	Fan: speed 1≈58H, speed 2≈33H, speed 3≈24H, speed 4≈16H LED Lights: level 1≈120H, level 2≈40H, level 3≈16H When turning on the fan & the LED lights at the same time on the highest setting, it will last for 8 hours.

5. Attentions

- 1) Do not expose the product to high temperature, fire or under the Sun;
- 2) Do not put the product in humid place;
- 3) Do not throw the product into a fire or approach a fire to avoid fire disaster;
- 4) Do not disassemble, cut or pierce the product;
- 5) Please stop using if abnormal conditions happen during the use of the product;
- 6) Please charge the product every 2-3 months if not used for a long time, to avoid damage to the battery.

Warranty card

Dear customer, thanks you for purchasing our company's products. Please read the instruction manual and save it for future reference. Please fill out the warranty card and place it in the mail.

Customer name:
Address:
Date of purchase:
Phone number:
Email:
Product model#:

