

User Manual

Model: WS15


Introduction

Thanks for choosing our wearable wireless speaker WS15. This is a multifunctional wireless speaker with professional-quality for music playing. If you want to have a better experience, please read this instruction carefully.

Important

The speaker is shipped from the factory in deep sleep mode to conserve battery power. For first use, please connect the USB cable to a power source to activate the speaker.

Introduction



① Power button

② Volume up/ Previous song

③ Volume down/ Next song

④ PTT button

⑤ Microphone

⑥ Charging port

⑦ Spring clamp

Specifications

Wireless Version: 5.4
Rated output power: 2.4W
Battery Type: lithium battery
Battery Capacity: 3.7V/600mAh
Playing Time: up to 18 hours at 70% volume
Charging Time: 2H
Waterproof Level: IPX7
Product Size: 73x42.9x28.2mm
Product Weight: 70g

BUTTON OPERATION



(1) Press and hold for 3 seconds to power on/off.

(2) Music Mode:
Short press to play/pause music.

(3) Restore Factory Settings:
While powered on, press the button five times in quick succession to clear the paired MAC address and restore the device to its factory default settings.



(1) Calling Mode:
Short press to increase the volume.

(2) Music Mode:
Short press to increase the volume.
Press and hold to skip to the next song.



(1) Calling Mode:
Short press to decrease volume.

(2) Music Mode:
Short press to decrease volume.
Press and hold to go to the previous song.



Note: This key is a dedicated control key for voice intercom PTT, if you need to use intercom mode, please download the mobile phone ZELLO APP to add contacts and use this function.

Wireless Connection

1. Enable wireless on your device.
2. Press and hold the power button to turn on the wearable speaker.
3. Search for the wireless device named "WS15" on your device.
4. Select it to establish a successful connection.

Addressing Stuttering

1. Check the battery level and ensure it is adequately charged.
2. Ensure the devices are within a 10-meter range to maintain a strong signal.
3. Avoid potential sources of signal interference in the surrounding environment.

Warranty

1. All our products come with a hassle-free 18-month warranty, plus lifetime technical support.
2. Our standard for responding to email requests is under 12 hours.
3. For any inquiries regarding the wearable wireless speaker, please contact us via Amazon Messenger or by scanning the QR code below.



未注公差要求		名 称		型 号	
(mm)		制图	日期	比例	1: 1
尺寸小于1		±0.05	设计	日期	材料
尺寸小于20		±0.10	审核	日期	重量
尺寸小于50		±0.15	深圳市捷美斯实业有限公司		
尺寸小于100		±0.20			
尺寸大于100		±0.25			