



UPGRADED
VERSION

MULTIFUNCTIONAL BLENDER USER MANUAL

CUSTOMER SERVICE

Our customer service team is always ready to assist you if you have any issues or concerns.



www.vewiorlife.com



support@vewiorlife.com




1-888-285-6061

IMPORTANT SAFEGUARDS	01
PRODUCT OVERVIEW	03
USER GUIDE	04
TROUBLESHOOTING	05
CLEANING AND MAINTENANCE	06
DISPOSAL	07

To avoid electric shock, fire, or injury, please read the user manual carefully before using the blender and keep it for future reference.

1. The blender can be used by children aged 8 years and above
 - Children shall use or clean the blender with supervision.
 - Keep the blender and the power cord away from the children.
2. Fully unwind the power cord before use.
3. Do not use the blender if the power cord or power plug is damaged, or if the blender is dropped or damaged in any way.
 - If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified people to avoid a hazard.
 - Please contact the VEWIOR customer service team for a replacement if the blender is damaged.
4. Never immerse the motor unit, the power cord or the power plug in water nor rinse them.
5. Always cut off the power if it is left unattended, under assembling, or disassembling.
 - Please cut off the power when the blender is not in use.
 - Please cut off the power before putting on or taking off the cups.
 - Please cut off the power before pouring out the drinks.
 - Please cut off the power before cleaning.
6. The blender is strictly prohibited for no-load or overload operating.
7. The blender is intended to be used in household and other residential type environments.
 - Such as hotels, motels, farm houses and so on.

8. Unauthorized use or the use of attachments that do not belong to this product may cause fire, electrical shock or personal injury, or damage to the appliance.
9. Make sure the cover and the cup securely locked in position before use.
 - Tighten the cup clock-wisely to the locked position of the safety lock.
10. Take care while using, replacing or washing the sharp cutting blades or emptying the cups to avoid injury.
11. Keep hands and utensils away from the using blender to avoid injury to people or damage to the blender.
 - To reduce the risk of injury, please place the blades cutter-assembly on the base.
12. Do not use the blender for too long, otherwise it will easily cause high temperature and cause the cup body breaking.





Shaker Lid



Solid Lid



To-Go Lid

Low Cup
(300ml)sport water bottle
(500ml)High Cup
(650ml)

Motor Base

2-Leaf Flat
Blade6-Leaf Cross
Blade

Food	Fruits & Vegetables	Coffee beans & nut
Blade Type	Cross Blade	Flat Blade
Cup Type	High Cup	Low Cup
Time	60 seconds with the recommended max 500ml loaded capacity with water	30 seconds with the recommended max 150g loaded capacity

1. Place the cup on a flat surface with the open end facing up. Fill the cup with your favorite ingredients.
 - Make sure not to exceed the maximum mark of the cup.
2. Attach the blade on the cup and attach cup on the motor unit. Power on to blending.
 - Place the mixing cup upside down on the machine with the three raised clips lining up with the three grooves in the machine.
 - Press the mixing cup with the hand and tighten it clockwise.
 - There are 3 kinds of blender modes to choose including: "1" mode, "2" mode & "pulse" mode.
 - Rotate the knob to "0" to turn off the blender.
3. Unplug the machine once it blended. Unscrew the cutter seat assembly and pour out the food.
 - Press the mixing cup down and rotate counterclockwise to take out the it.

***** The appliance doesn't work.**

- 1) Check if the power cord is plugged into the outlet properly.
- 2) If it still does not work, please contact us and we will provide 12-month replacement or return service.

***** Can I blend hot foods?**

No. NEVER blend hot foods in a blender. Cool the food to a temperature that is lower than 60 °C (140 °F).

***** Blender stops while blending.**

Unplug the power cord, take out the cup and try to:

- 1) Shake the cup,
- 2) Reduce the loaded capacity.

***** How to crush ice cubes?**

- 1) Don't put too many ice cubes at a time to prevent the blade from jamming.
- 2) Don't blend continuously for more than 20 seconds
- 3) It is recommended to use the pulse mode intermittently several times quickly. two-second bursts until the ice cubes are crushed completely.
- 4) Please add enough liquid (more than one third).

1. Remove the cross/flat blade attachment from the cross blade plastic base by pushing the blade gear.
2. Remove the gasket ring.
3. Wash the gasket ring and the cross blade attachment to clean the debris, then rinse with water.
4. Dry well in a cool place.
5. Assemble the extractor blade.
 - Please ensure the gasket ring attached properly.
6. Cut the power off when the blender is not in use.
7. Please store the appliance in a dry & well-ventilated place when it is not in use for a long time.
8. The accessories can be washed under running water.
9. Clean the blender with a dry cloth.
 - To avoid the risk of electrical shock, never immerse the motor base in water or place it under running water.

The appliance should not be disposed off via the household bin collection. Disposal of the appliance should be carried out in accordance with the national regulations. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

When replacing the old appliances with new ones, the retailer is legally obligated to take back the old appliance for disposal.



www.vewiorlife.com



support@vewiorlife.com



1-888-285-6061

