

# **INSTRUCTIONS FOR PROPER USE AND CARE OF YOUR ULTIMATE® HOSE NOZZLE**

Should your nozzle operate improperly, it may be due to dirt or debris inside the nozzle. If this happens, it could cause the spray pattern to be irregular. Your nozzle is designed for easy cleaning: Simply insert a 5/32" Allen Wrench into the "Hexagonal" screw head of the nozzle. After removing the screw, unscrew the barrel from the hose stem and if dirty wash/clean out the debris. Put the nozzle back together in the same fashion as you took apart making sure the "Hexagonal" screw is secured tightly in place. Keeping the nozzle clean will insure correct operation.

Note: If the Lubrication on the black stem and O-rings is removed re-lubricate with clear silicone grease, available at any hardware store.

---

## **IMPORTANT:**

**DURING THE WINTER SEASON OR FREEZING COLD TEMPERATURES, REMOVE THE  
NOZZLE FROM THE HOSE AS RESIDUAL/STANDING WATER CAN  
FREEZE/EXPAND AND CAN DAMAGE THE NOZZLE.**

## **ATTENTION:**

**FOR MAXIMUM PERFORMANCE USE A 5/8" OR LARGER WATER HOSE.**

**If you have any questions regarding the operation of your ULTIMATE® HOSE NOZZLE  
please contact:**

**Customer Service Department**

**Bon-Aire Industries, Inc.**

**873 E. Citation Court**

**Boise, ID 83716**

**Toll Free: 800-874-5771**