

MUNBYN

More choice for your growing business

Version: 2.00

MUNBYN

IDS002 Easy Setup Guide



Contents

1.0. Product Introduction

1.1. What's in the Box 1

1.2. Product Overview 2

1.3. Display Interface 2

2.0. How to use the scanner

2.1. Before Scanning 3

2.2. How to Start Scanning 3

2.3. Scanned Files Previewing 4

2.3.1. View the scanned files on the LCD screen 4

2.3.2. View the scanned files on the computer 4

2.4. Wi-Fi Connection 4

3.0. Menu Setting

3.1. DPI Setting 6

3.2. Color Setting 6

3.3. Format Setting 6

3.4. Date/Time Setting 6

3.5. For More Settings, Please Refer to The Online User Manual 6

4.0. OCR Software Operation Guide 7

1.0. Product Introduction

1.1. What's in the Box

When you receive the package, open and check the packing list in it.



Figure 1- 1 What's in the Box

1.2. Product Overview




Figure 1- 2 Overview

1.3. Display Interface




Figure 1- 3 Display Interface

2.0. How to use the scanner

2.1. Before Scanning

- 1) Make sure the device has enough power to turn on, if the device does not have power, please plug in the power cord to charge.
- 2) Check that the SD card is inserted into the device, if no SD card is inserted into the device, please insert SD card into SD card slot.

2.2. How to Start Scanning

- 1) Press the button  and hold for 3 seconds to turn on the scanner.
- 2) Put your target (document/photo/receipt/book) on a flat desk, placing the scanner on the position of target you want, press the button  to start scanning, when the document icon is displayed on the LCD screen, slide the scanner over the target smoothly and slowly.



Figure 2- 1 Document Scanning Mode

- 3) Press the "SCAN" button to end scanning, then the device will automatically jump to the preview interface for 3 seconds, you can preview the scanned file for 3 seconds.

Demo video: <https://munbyn.biz/002s>

Note: About size: The maximum size of the scanned target is 8.27 inches. If the target is over this limit, it is recommended that you perform segmented scanning reasonably.

2.3. Scanned Files Previewing

- 2.3.1. View the scanned files on the LCD screen

Press the button  to view the scanned files. In addition, the file supported zoom in twice by press the button  and the third time you press will return the file to original size.

- 2.3.2. View the scanned files on the computer

Connect the device to the computer with the attached USB cable. At this time, a picture of the USB interface will be displayed on the LCD screen to enter the USB mode. Open the corresponding SD card disk of the computer, and you can view the scanned files.

If you want to connect to the computer by Wi-Fi to view the scanned files, please refer to 2.4.

2.4. Wi-Fi Connection

Turn on the scanner Wi-Fi → The device connects to the scanner Wi-Fi → Browser enter the IP address → Enter username and password

- 1) Press the button , then select the WiFi Link by the button , finally press the button  to start up the Wi-Fi.
- 2) Wait about 30 seconds, the LCD screen will display Wi-Fi sign.



Figure 2- 2 Wi-Fi Sign

- 3) Enable the Wi-Fi function of your device (computer, mobile or tablet), click the "Scanner xxx"(xxx is the scanner number) icon from the network list of your devices.
- 4) After it connects successfully, open your web browser, enter the address 192.168.10.1 in the web address field and hit enter key to reach the Wi-Fi home page.
- 5) The Wi-Fi home page will ask you for a username and password, then you can view and download the scanned pictures in scanner.

Note: Default username: admin

Default password: admin

Demo video: <https://bit.ly/IDS002-video>

3.0. Menu Setting

3.1. DPI Setting

The DPI setting can adjust the scan resolution. On the standby interface, press the button , and there are three scanning resolutions to choose from, including LO (LOW 300DPI) / HI (HIGH 600DPI) / FI (FINE 1050DPI), the higher the DPI level, the clearer the scan image.

3.2. Color Setting

Enter the menu interface and select the color mode, and there are two color modes to choose from, including Color mode and Mono mode. The color mode means that the scanned image is colored. Conversely, mono mode means that the scanned image is monochrome.

3.3. Format Setting

In the standby interface, press the button , and there are two formats to choose from, including JPG and PDF.

3.4. Date/Time Setting

With the time setting function, you can easily know the scan date of the document. (In this mode, the button  represents increase and the button  represents decrease.)

Model video: <https://munbyn.biz/002t>

3.5. For More Settings, Please Refer to The Online User Manual

Online user manual: <https://munbyn.biz/IDS002>

4.0. OCR Software Operation Guide

Note: You can use OCR software to convert non-editable documents such as PDF and images into editable formats, such as word or excel.

OCR software download link: <https://munbyn.biz/ocr>

Model video: <https://munbyn.biz/001ocr>

Contact us



Scan the QR code
for Facebook online chat

MUNBYN provides 18 months warranty and lifetime free service.

If you encounter any issues with the product, please contact the MUNBYN team to promptly receive troubleshooting tips or a replacement.

✉ support@munbyn.com (24-7 online support)

🌐 www.munbyn.com (how-to videos, warranty details)

☎ +8617817881067