




Geekee G450 True Wireless Earbuds

PACKAGE CONTENTS

- Geekee G450 Wireless Earbuds
- On-the-go Charging Case
- 4 Pairs of (XL, L, M, S) M size are already attached Silicone Eartips
- 4 x Earhook Cover
- 1 x Charging Cord
- User Manual

PRODUCT DIAGRAM

- ① Multi-function Button
- ② LED Indicator
- ③ Charging Contact
- ④ Micro USB Charging Port
- ⑤ Charging Case LED Indicator



PRODUCT SPECIFICATIONS

Product Name	Geekee G450
Bluetooth Version	V5.0
Operation Range	< 33Feet(Unobstructed Effective Range)
Earbud Charging Time	< 90 minutes
Charging Case Charging Time	< 150 minutes
Play Time	3-3.5 Hours (at 75% volume)
Talk Time	3 Hours (at 75% volume)
Standby Time	160 Hours
Bluetooth Profiles	A2DP, AVRCP, HFP, HSP
Earbud Battery Type	50mAh Rechargeable Lithium Batteries
Charging Case Battery Type	500mAh Rechargeable Lithium Batteries

HOW TO CHARGE

Charging The Earbuds

When the battery is low, the LED indicator flashes white with a voice prompt to remind you of a low battery. To recharge the earbuds, simply place them in the charging case and close the case. The earbuds LED indicator turns white and then shuts off when fully charged.

Charging The Charging Case

To power up the charging case, simply plug it into a USB power supply, the charging case LED will flash blue when charging, and the blue light will remain on when fully charged. (Please check the battery level and charging status as indicated below.)

Battery Level	The Charging Case LED Indicator Light Status
0 - 33%	One light flashes
33 - 66%	One light keeps on, second light flashes
66 - 99%	Two lights keep on, third light flashes
100%	Three lights keep on

HOW TO PAIR

First Time to Pair with Devices:

- Take both earbuds from the charging case, both earbuds will power on and connect with each other automatically. You will hear a voice "pairing" indicating that the earbuds are in pairing mode.
- Enable Bluetooth on your device and select "Geekee G450". You will hear a voice "pairing successful, second device connected" once connected.



Second Time to Pair with Latest Devices:

Take the earbuds out of the case, it will pair with your latest device automatically. The earbuds turn off automatically when you put them back to the charging case. To manually power off, long press either earbud multi-function button for 6 seconds; To manually power on, short press both earbuds multi-function buttons.

HOW TO USE MONO MODE

Right earbud for mono mode:

Take the right earbud out of the charging case, it will power on and enter pairing mode automatically, enable the Bluetooth on your device and search "Geekee G450", tap to connect. If the left earbud has been used for stereo mode last time, just pick it up and it will connect with your last connected device automatically.


Left earbud for mono mode:

Take the left earbud out of the charging case, it will power on automatically. You will hear a voice "pairing" indicating that the earbud has entered pairing mode, it will enter pairing mode, enable the Bluetooth on your device and search "Geekee G450-L", tap to connect.

NOTICE FOR PHONE CALL UNDER TWS MODE:

Both earbuds could hear the voice of calling, but only right microphones are available for talking during phone call under TWS mode. Due to deficiency of current Bluetooth technology, it would be improved sooner or later depending on the development of Bluetooth technology.

HOW TO WEAR



HOW TO RESET PAIRING

Take both earbuds out of the charging case, quickly double-click both earbuds multi-function buttons until the LED indicator turns white, wait for about 10 seconds, you will hear "Pairing Successful" "Connected" "Left Channel" "Right Channel".

HOW TO CARE FOR YOUR EARBUDS

Always store the earbuds in the charging case and safely protected. Avoid storage at extreme temperatures (Above 65°C/149°F or below -10°C/14°F). Otherwise, it would shorten the battery life and may affect the earbuds.

CONTROLS

Listening to Music

▶ Pause Music	Press either earbud button for once.
⏮ Play Music	Press either earbud button for once.
⏪ Forward	Press right button for 2 seconds.
⏩ Backward	Press left button for 2 seconds.
🗣 Activate/Stop Siri	Double Press either earbud button

Making and Answering Calls

☎ Answer call	Press either earbud button for once.
📞 End Call	Press either earbud button for once.
📞 Reject Call	When a call is incoming, press either earbud button for 2 seconds.
💬 Switch Phone Chat Device	During a call, press either earbud for 2 seconds to switch chat between the earbud and your phone.

FAQS

Questions	Answers
Q1: The right earbud can not connect with the left earbud	Refer to "HOW TO RESET PAIRING"
Q2: Can't turn on the earbuds.	A1: Check whether there's battery left in the charging case. Charge the charging case then try again if this is the case. A2: Put the earbuds back to the charging case to fully charge the earbuds, then try again.
Q3: Can't pair successfully with your device.	A1: Remove the earbuds Bluetooth from your device. A2: Reset the earbuds, search "Geekee G450" on your device, tap to connect.
Q4: The right earbud cuts out and in.	A1: Wear the earbuds in a correct way. (Refer to "HOW TO WEAR") A2: Disable the connection between the earbuds and your device, pair with the device again.
Q5: Still get problems?	Feel free to contact us at support@getgeekee.com . We will reply back within 24 hours.

CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical & Electrical Equipment)
This symbol shown on the package or its literature indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

WARRANTY

Geekee G450 comes with an industry-leading 12 months warranty that begins from date of purchase.

The warranty applies to the Geekee G450 Bluetooth Earbuds and necessary parts. The warranty does not apply to damage resulting from failure to follow the operating instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

PRODUCT REGISTRATION

If you want to register your product for warranty or become one of our power users, please feel free to send us an email at:

support@getgeekee.com

ARE YOU 100% SATISFIED?

If you have product questions or concerns, don't hesitate to contact us directly at:

support@getgeekee.com

Geekee has an award-winning warranty, exchange, and customer service program that guarantees hassle-free solutions to any issue you might have within 24 hours.