

AWESOME!

C O C O O N B E A N B A G



QUESTIONS?



SERVICE@JAXXLIVING.COM




1.866.384.2802


JAXXX[®]



COCOON BEAN BAG SET-UP INSTRUCTIONS



Unroll plastic film. Do not cut open or remove protective liner.



Confirm that the childproof zipper pull has been removed.




Flip & knead the foam to introduce air back into the micro-cushions.



Micro-cushions will take 24 hours or more to fully expand but the cover can be applied after 20 minutes.



Match the seams of the cover and liner and zip closed. Enjoy!



OPTIONAL: Use a paper clip to open the childproof zipper to add or remove foam from the liner.



To clean, remove the cover, machine-wash cold with mild detergent and hang dry. Do not wash the inner liner.