


A man in a dark hoodie and shorts is running on a wooden boardwalk. In the background, a suspension bridge and a city skyline with various skyscrapers are visible under a warm, orange sky.

RICOCHET

SOCCER REBOUND SCREEN

ASSEMBLY GUIDE & USER MANUAL

**TRAIN
TO WIN**

aceletiqs.com
support@aceletiqs.com



WELCOME

HELLO AND WELCOME

We founded Aceletiqs because we wanted to provide high-quality sports equipment at affordable prices. Whether you're on the team or in the stands rooting for your favorite team, we've got you covered.

Our sports training equipment allows players of all ages and all levels to improve their athletic skills in a wide range of sports. Have fun and maximize your athletic performance with Aceletiqs products.

At Aceletiqs, we're building a community to support players, coaches and parents. You put your heart and soul into your sport. Know that we're in your corner, cheering you on.

Abe and Schneur
Aceletiqs Co-Founders

**TRAIN
TO WIN**

QUICK START GUIDE



The Ricochet Soccer Rebound Screen is the ideal practice partner, helping athletes of all levels and ages improve their passing, receiving, and shooting skills. Enhance precision of penalty-, corner-, and free-kicks and overhead throw-ins. With the Ricochet, players can focus on critical fundamentals such as toe, push, instep, outstep, laces, back-heel, and volley kicks.

The screen is double-sided to accommodate individual or multi-player training. Customize the level of bounce-back the screen provides with the included heavy-duty bungee cords. Athletes from a wide range of other sports, including lacrosse, volleyball, field hockey, baseball, fastpitch, and softball, can also use the Ricochet to improve their sports performance.

FEATURES

12' wide x 6' high x 5' deep


72 sq. ft. surface area

Easy on-field assembly and disassembly

All-weather net with bungee cords

Double-sided for individual or multi-player training

WHAT'S IN THE BOX



FIRST STEPS

1. Remove the hardware from the shipping box and inspect for shipping damage.
2. Read carefully through this guide and all safety instructions.
3. Go to [aceletiqs.com](https://www.aceletiqs.com) and register your product within 14 days of purchase to activate your lifetime warranty.
4. Follow the easy 7-MINUTE ASSEMBLY GUIDE on the next pages.

CUSTOMER SUPPORT

Questions about assembling your soccer rebound screen? We're here to help. Email us and our experienced customer support team will be happy to assist you: support@aceletiqs.com.

SETUP INSTRUCTIONS

1. Set up the Ricochet Soccer Rebound Screen in an open location. Make sure there is at least 30 feet of clearance around the perimeter of the screen so that balls will not injure people and pets, or damage houses, cars, or other structures.
2. Place the screen on a level, well-drained surface.
3. Stake the screen to the ground using the four included galvanized steel ground stakes.



7-MINUTE ASSEMBLY GUIDE

STEP 1

1. Gather hardware labeled [1] - [7], to assemble the frame of the rebound screen.
2. Assemble the frame as shown in **Fig. 1**.
3. Insert the six included bolts, three on either side of the frame.




Figure 1. Assemble the frame

7-MINUTE ASSEMBLY GUIDE

STEP 2

1. Place the six included wing nuts on the ends of the bolts and tighten. Use the included Phillips screwdriver to help tighten the bolts and wing nuts. See **Fig. 2**.
2. Secure the rebound screen to the ground using the four U-shaped ground stakes. See **Fig. 2**.




Figure 2. Secure the frame

7-MINUTE ASSEMBLY GUIDE

STEP 3

1. Use the included bungee cords to attach the net to the frame. See **Fig. 3**.
 - a. Loop each bungee cord around the frame and through the edge of the net.
 - b. First, place one bungee in each corner. Then, attach the top and bottom. Finally, attach the sides.
 - c. Bungees should be spread about 6-8 inches apart.
 - d. You will need 12 bungees each for the top and the bottom, and 8 bungees for each side.




Figure 3. Install the net

SAFETY INSTRUCTIONS

PLEASE KEEP THIS MANUAL IN A SAFE PLACE FOR REFERENCE.

WARNING: To avoid injury or damage to property during assembly, disassembly, use, adjustment, and/or movement of the Ricochet Soccer Rebound Screen, the following warnings **MUST** be observed at all times:

RESPONSIBILITIES

1. It is the responsibility of the owner to ensure that all users of the Ricochet are adequately informed of all safety instructions.
2. Use the Ricochet only as instructed in this manual.
3. To prevent injury, children should not use the Ricochet until properly instructed.
4. Adult supervision is required at all times.
5. Only use appropriate balls (soccer, lacrosse, volleyball, baseball, softballs) with the Ricochet. Small balls such as golf balls will go right through the holes in the net.

DOS AND DON'TS

1. Place the screen on a level, well-drained surface.

SAFETY INSTRUCTIONS

2. Stake the screen to the ground using the included galvanized steel ground stakes.
3. Setup the Ricochet in an open location. Make sure there is at least 30 feet of clearance around the perimeter of the screen so that balls will not hit or damage people, pets, houses, cars, or other structures.
4. Keep hands, fingers, hair, and clothing clear of moving parts.
5. When first using the screen, stand at least 30 feet away so that you can safely get familiar with the speed and power of rebounded balls.
6. If using the Ricochet indoors, secure to the ground with sand bags or other appropriate weights.

EQUIPMENT CARE & MAINTENANCE

1. Always check for loose or missing bolts and for damage to the bungees and netting before use. Loose bolts should be tightened.
2. We recommend storing your Ricochet indoors. Water and UV rays will damage the bungees over time and make them less effective.



At Aceletiqs, we create quality, long-lasting sports equipment. We guarantee that quality with a lifetime warranty on all of our products.

If your product ever breaks, we will send you replacement parts. If your product cannot be repaired, we will send you a replacement, free of charge.

Register at aceletiqs.com to activate your warranty within 14 days of purchase.

PRODUCT SPECIFICATIONS

UNIT SPECIFICATIONS

Dimensions: 12' W x 6' H x 5' D

Weight: 36 lbs.

Frame: 18-gauge, 1.25" steel

Netting: 5-ply 1.75" knot-less net with 420d fabric

Screen Angles: Double-sided

Ground Stakes: Galvanized steel

MADE IN CHINA

RICOCHET
Soccer Rebound Screen


BODYGUARD

Pitcher Protection L-Screen

Stay safely out of the line of fire with the Bodyguard Pitcher Protection L-Screen. The protection screen is perfect for baseball, softball, and fastpitch. Built to provide lasting protection, the frame is high-quality steel. The #42 double-pillowcase netting slides quickly and easily over the frame.

FEATURES

- » 1-1/2 inch steel frame
- » Waterproof netting
- » Simple to assemble
- » Easy to transport to practice and games



BULLSEYE

9-Hole Pitcher's Pocket

Practice your pitching accuracy in all areas of the strike zone with the Bullseye 9-Hole Pitcher's Pocket. The pitcher's pocket is perfect for athletes at all levels who play baseball, fastpitch, and softball. Durable netting withstands even the toughest pitchers, long into the future. High density netting is securely fastened to the 14-gauge steel frame and protected by thick, protective foam and heavy-duty vinyl.

FEATURES

- » 22" W x "22" H x 3" L
- » 1-1/2 inch steel frame
- » Heavy-duty #60 netting
- » Simple to set up and take down
- » Easy to transport to practice and games





aceletiqs.com

TRAIN
TO WIN

📷 Aceletiqs

📘 Aceletiqs

support@aceletiqs.com