

# FEELLE EN2053

## Wireless Meat Thermometer

### Quick Start User Manual



Open the cover



Install the batteries



Close the cover




Insert the probes

# 4 Simple Steps to Get Started to Use



## Step 1



Press the **MODE** button to choose PROBE:1 or PROBE:2

## Step 2




Press the **MEAT** button to choose meat type(8 Types-beef,veal, turkey.etc.)

## Step 3




Press the **TASTE** button to choose taste level (5 Levels from RARE to WELL)

## Step 4



Press the **(( )) / °C / °F** button to turn on the Alarm function

## Step 1



Press the **MODE** button to select PROBE 1/2

## Step 2




Press the **MEAT** button to select Meat Type-PROGM

## Step 3



Press and hold the **MODE** button until the temperature value blinks

## Step 4



Press **UP/Down** to set your desired temperature

## Step 5



Press the **MODE** button to confirm the temperature setting

## Step 6



Press the **((•)) / °C / °F** button to turn on the Alarm function

# How to Set Your Specific Taste?



## Count UP/Down Timer

### Step 1

Press the **UP** (Min) / **Down** (Sec) button to adjust time setting

### Step 2

Press **ST/SP/CLEAR** button to start the timer

### Step 3-Stop Timer

Press **any** button to stop the timer

### Step 4-Clear the timer setting

After stopping the timer, press and hold **ST/SP/CLEAR** button for 2s to clear the timer setting

