TYROLER® BRIGHT TOOLS

www.tyrolerltd.com


# The Glider AFC

## DOUBLE SIDED, MAGNETIC CLEANER WITH A SMART ADJUSTABLE FORCE CONTROL


The magnetic force control system allows you to adjust The Glider to work with a wide range of window thick single, double or triple - For big and hard to reach windows, it cleans the exterior of windows, while staying in the room.



1. Apply cleaning solution generously on both sides of the window.




2. Separate the two sides of the Glider.




3. Place the plastic ring, (at the end of the safety string) on one of your fingers.




4. Place the two parts of the Glider on either side of the window, (small piece on the outside).



5. Guide the Glider across the glass in an "S" shape to remove the water. Remaining drops and streaks of water will be removed on next step.



6. Place the microfiber cloth on both parts of the Glider.



7. Dry and shine your window. In case that the water streaks dried off, you may apply cleaning solution, or clear water on the microfiber cloth.

### Safety instructions

Watch your fingers, the Glider contains strong magnets.
Hold safety rope while cleaning.
Keep away from: children, pace makers and electronic equipment.

**Comments:**

For very dirty windows attach the wet cloth to the Glider and scrub the window thoroughly, before proceeding to step # 4

To prevent detachment during cleaning, turn slowly around corners to avoid hitting the frame. Always pay attention to the piece on the outside.
Make sure the rubber blades are always wet. Maintain light pressure as you move the Glider across the window. Use only Glider micro fiber cloth. (It has low friction on the window).

**If you need any assistant please do not hesitate and let us know, we promise to help:**

**support@tyroler.co.il**

**See a short video at our website, which demonstrates the operation Of the Glider.**


WATCH NOW

TYROLER®
BRIGHT TOOLS


www.tyrolerltd.com

# Adjustable Force Control glider

In order to adjust the glider force to your window you have to estimate your window thickness.



For single glazed windows (from 2 mm to 8 mm), open the adjustable screw fully, then start working with it. If the grip is too weak, turn the wheel clockwise until the grip is strong enough.




For double-glazed windows, open the screw to half, start working with the gliders. If the grip is too weak, close it and turn the wheel clockwise until the grip is strong enough.
If it is too strong, turn the screw counter-clockwise until the grip becomes easy.

# Warning





Always keep the two parts of the glider separate.
Since the magnet is very strong, make sure they're apart when the screw is closed

In order to prevent your fingers from getting caught between the glider parts, make sure to not keep them too close to one another. Parts can abruptly magnetize to each other.




Keep gliders parts at least 20 cm away from each other.




Once you finish cleaning the windows, lay the glider parts away from each other with the magnet side facing the floor, not each other (see image)



How to release the two parts from each other (lower the strength of the magnets)
If the two parts of the glider got magnetized to each other, here is how you can separate them:
Twist both screws all the way up. In this mode, the magnet power is lower and will allow you to separate the parts and start cleaning your window.

## Customer satisfaction is our top priority!

For any questions or requests, please don't hesitate to contact us.
We promise to provide you the most efficient solution.

Further questions and information can be referred to our product manager:

**support@tyroler.co.il**

**WhatsApp: +972547872242**