

OHS

ONLINE HOME SHOP

Electric Heated Over-Blanket User Guide

Product Information


130cm x 160cm

100% Polyester

Voltage: 220-240V

Power: 85W

Model Number(s): OBEBFHBGY13/OBEBWFLCL13/OBEBTDFCL13/OBEB-SHRGY13/OBEBFLCCL13



Single Controller
with 9 Heat Settings



Safety Overheat
Protection




Detachable Cord
for Easy Washing



Quick Heat-up
Time

Description of Parts



Included:

- 1 x Cardboard Gift box
- 1 x Electric Blanket
- 1 x Detachable Wire controller
- 1 x User Guide

A - Main Blanket

B - Heat Panels (inside the blanket)

C - Adaptor

D - Detachable wire

E - Controller, C-22

F: 3 Pin Plug

Using your Electric Blanket

- Once the blanket has been unfolded, attached the powercord
- Use the controller to choose a heating setting to your preference, 1 is the lowest setting and 9 is the highest.
- Use the controller to set the timer for between 1 and 9 hour (NOTE: do not use the timer to keep the blanket on over night, only use when awake and alert).

Washing Instructions



Wash at 30°



Do not Dry Clean



Do not Tumble Dry



Do not Bleach



Do not Iron



Do not Wring

ALWAYS DISCONNECT THE CONTROLLER AND POWER LEAD FROM THE BLANKET BEFORE WASHING.

- Machine wash at 30°
- Avoid the use of harsh cleaning chemicals or bleaches
- Do not tumble dry or iron
- NEVER wring dry this item
- Air dry flat on a line or flat surface
- Do not plug in to dry
- Always ensure the blanket is 100% dry before use after washing

Safety Instructions

- Important instructions, please retain for future use.
- After Unpacking, check the product for signs of transit damage - do not use if damage is found
- Regularly check the blanket for signs of wear or damage before use, do not use the blanket if damage is found
- Indoor use only
- Not to be used by persons sensitive to heat and other vulnerable people who are unable to react to over heating.
- Keep away from fire or flammable materials.
- Do not insert pins or sharp objects into the blanket.
- Do not use when wet or around liquids or damp environments
- Do not use power cord with wet hands.
- Do not use the blanket when folded or creased.
- Unplug electrical power cord when not in use, take care when storing the cord to avoid damage to the wires
- Only operate with the supplied lead and controller
- Do not overheat the controller or trap it under a pillow, mattress or blanket.
- Do not use with sofa beds, inflatable beds or adjustable beds.
- Do not use a hot water bottle at the same time when using the blanket.
- Do not fall asleep using this product
- NEVER allow a child or infant to use this product
- Do not put in a child or pet bed
- This is not a medical device
- This product is not a toy
- This device should not be ammended or repaired by anyone other than a qualified professional
- Do not use in conjunction with a timer or extension plug

Storage when not in use

- Remove and safely store the cable separatly from the blanket
- When storing the blanket, allow it to cool down fully before loosely folding or rolling up the blanket. Make sure the blanket is stored without any heavy items on top, this could cause deep creases and damage to the wiring.
- Do not crush the blanket in a small storage cupboard, this may cause damage to the wiring.

Disposal

- If you no longer wish to use the appliance, make sure it is unusable by cutting the power lead when disconnected. Do not dispose of the device in the household waste, dispose in accordance with

KEEP AWAY FROM FIRE AND FLAMES




Please dispose of in the correct manner and separately from domestic waste.



Do not insert pins.




Not to be used by children.



Warning electricity.



Warning: Warning of risks of injury or health hazards.



The blanket has double protective insulation and therefore complies with protection class 2.

CE UK
CA

OHS

ONLINE HOME SHOP

For any product support please
contact our Customer Service team:
csmarketplace@onlinehomeshop.com