




Wall Lantern
Owner Manual
Model 5293201012



**IMPORTANT
RETAIN FOR FUTURE REFERENCE
READ CAREFULLY**

For assistance please contact our customer service hotline Monday-Friday 9 a.m-5 p.m Eastern Standard Time

Toll Free 1-(877) 714-8669 (English speaking only)

LUTEC USA CUSTOMER SERVICE


149-B Houston Rd Troutman, NC 28116

E-mail: service@lutech.net

Website: www.lutech.com

English

PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
A	Fixture	1
B	Lamp Shade	1
C	Fixing ring	1
AA	Screw	2
BB	Wire Nut	3
CC	Connector	1
DD	Bulb	1
EE	Nut	2
FF	Mounting Crossbar	1

SPECIFICATIONS:

Model: 5293201012

Total power: 12W

Lumens: 1,000lm

Voltage: 120V

Hertz: 60Hz

Measurements: 18.66 in x 11.81 in x 12.48 in/47.4 cm x 30 cm x 31.7cm



SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.



WARNING:

- Consult a qualified electrician if you are not certain about the installation process. Always install wiring connections in accordance with local code, ordinances and the National Electric Code.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This light fixture is designed to fit standard junction boxes as defined by the National Electrical Code.
- This light fixture is not dimmable.

NOTICE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

REPARATION

Before beginning to assemble or installing lighting fixture, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble, install or operate the product.


Estimated Assembly Time: 20-30 minutes.

Tools Required for Assembly: Phillips Screwdriver, Silicone Caulking Adhesive, Ladder.


INSTALLATION

1. Turn OFF power to work area at main circuit breaker or fuse box.


CAUTION: Do not rely on wall switch alone to turn off power.




2. Remove the mounting crossbar (FF) in the fixture (A) by unscrewing the nuts (EE), then detach the fixing ring (C) from the fixture (A).




3. Attach the mounting crossbar (FF) to the junction box (not included) using the two screws (AA). Make sure the bracket with the two mounting screws that attaches to the fixture (A) is level. If it needs to be adjusted, loosen the Philips screws in the center of the Mounting Crossbar, then tighten when level.




4. Locate the ground wire from the junction box and connect it to the green ground wire from the connector (CC) by twisting a wire nut (BB) onto the bare ends of the wires. Connect the white wire from the junction box to the white wire from the connector (CC) by twisting a wire nut (BB) onto the bare ends of the wires. Connect the black wire from the junction box to the black wire from the connector (CC) by twisting a wire nut (BB) onto the bare ends of the wires.




5. Install the lamp shade (B) to the fixture (A) by tightening the fixing ring (C) removed in step 2. Then install the bulb (DD).



6. Connect the connector (CC) to the fixture (A). Position the wires inside the junction box.





7. Position the light fixture (A) over the two screws from the crossbar and tighten the two nuts (EE) that were previously removed in step 2.




8. Turn ON power to work area at main circuit breaker or fuse box.

Note: To check if the fixture is operating properly, cover the photocell with your fingers so no daylight can reach the photocell. The light should turn on and turn off when you remove your fingers. If the fixture is installed in a shaded or covered area where there is little direct sunlight, the light may come on during the day.




9. After mounting the fixture, apply silicone caulking compound completely around the perimeter of the cover plate where the back of the cover plate meets the mounting surface. Silicone caulking prevents water from seeping into the junction box.



OPERATING INSTRUCTIONS

The photocell in the fixture is designed to detect light and prevent the fixture from turning on when it senses daylight. At dusk, the light will turn on throughout the night until dawn. At dawn, the light will turn off throughout the day until dusk.

Note: To check if the fixture is operating properly, cover the photocell with your fingers so no daylight can reach the photocell. The light should turn on and turn off when you remove your fingers. If the fixture is installed in a shaded or covered area where there is little direct sunlight, the light may come on during the day.



CARE AND MAINTENANCE

- Clean surfaces with a mild, non-abrasive cleaner.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The light will not go on.	1. No power to light. 2. There may be a poor connection between the light and supply wires inside the junction box. 3. The photocell detects light or sunlight nearby.	1. Check that the circuit is on, wall switch is on, and there is power to light fixture. 2. Check supply wire connections. 3. Avoid light directed at the photocell at night. Cover photocell with your hand.
The light comes on during the day.	1. The fixture may be installed in a relatively dark location. 2. There is dust on the photocell.	1. Relocate the fixture. 2. Periodically clean the surface of the photocell with a mild, non-abrasive cleaner.
The light flashes.	1. Something is reflecting the light.	1. Relocate the fixture away from reflective surfaces.

5-YEAR LIMITED WARRANTY

If this product fails due to a defect in materials or workmanship within five (5) years (Battery and bulbs excluded) from the date of purchase, return it along with proof of date of purchase and it will be replaced with the same or comparable model free of charge by LUTEC USA LLC..

This warranty is void if damage or defect has resulted from accident, abuse, misuse or faulty repair. This warranty gives you specific legal rights and you may have other rights that vary from state to state.

IN NO EVENT WILL LIABILITY EXTEND TO ANY CONSEQUENTIAL, SPECIAL, INCIDENTAL OR INDIRECT DAMAGES OF ANY KIND ARISING OUT OF THE USE OR MISUSE OF THIS PRODUCT. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca
* faisant affaire au Québec sous
le nom les Entrepôts Costco

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Spain S.L.U.
Polígono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku
Readjustment Area, Kaneda-Nishi
361 Urikura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr

Costco Wholesale New Zealand Limited
2 Gunton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco (China) Investment Co., Ltd.
Room 1003, Block 2, 2388 Xiupu Road,
Pudong New Area, Shanghai
China 201315
+86-21-6257-7065

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se

Imported by:
LUTEC USA LLC
149B Houston Road
Troutman, NC 28166
1-(877)714-8669
www.lutec.com

Made in China