
ROMOON®



User Manual
Laundry Sorter Cart

Model NO. LS-600

Introduction

Thank you for purchasing the Romoon LS-600 Laundry Sorter. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

Package Contents

Laundry Sorter Cart、Warranty Card、User Manual

Product Specification

Product Name	Laundry Sorter Cart
Model Number	LS-600
Color	Multicolor
Material	Iron, Fabric, PVC
Frame Dimension	100*43*80CM/ 39.37*16.93*31.50"
Bag Dimension	54*22*36 CM/21.26*8.66*14.17"
Weight	11.2 lb

Laundry Sorter Installation Notes

- Please read the user manual carefully before using the product.
- Before opening the product, please ensure the integrity of the product packaging is in place.
- We use 3D diagrams and text to make installation as easy as possible. If you have problems during installation, please contact us; we'll be happy to help.
- We designed the installation instructions according to the user experience. If you refer to other instructions, they are not suitable.

support@romoons.com

Note

- This product is only suitable for indoor use in homes and hotels.
- We recommend loading the same amount of clothing in each laundry bag.
- Laundry bags can be loaded with wet or dirty clothes. You can wipe them with a wet towel and dry them.
- The product has a slight odor that is normal for the material. After a few days of use, the smell naturally disappears.

Safety Warning

- For safe use, it is forbidden to put people or pets in the laundry bag. Users are prohibited from using it in direct sunlight, or around corrosive chemicals and vapors, as they can be destructive to all the materials of the cart.
- We do not recommend that you install parts other than this product on or in this product, as installation of other parts could reduce product safety and stability.
- The maximum load of the laundry vehicle is less than 50lb. We recommend that each laundry bag has an equal average load capacity in order to evenly disperse the weight. It is not safe to exceed the maximum load capacity.

Package Contents

- Please use after fixing the screw tightly to avoid unstable laundry sorter
- Please fix the wheel by hand. Do not use shoes or it will damage the wheel
- Please don't put the bag in laundry machine and it can be cleaned by a rag
- If you receive romoon products is smelly ,please place it in a ventilated place for one to two days and then the odor will disappear.


Warranty & Customer Support


For questions, assistance, or warranty claims, please contact us by email at Amazon Customer Service with your order number,and our team members are more than happy to help.

*Our team members will be glad to take care of you. If you are satisfied with Romoon product feel free to recommend our brand to your friends and family.

If you have any questions, please feel free to send questions to our email: **support@romoons.com**

Unit list


Tag	❶	❷	❸	❹	❺	❻	❼	❽	❾
Image									
Quantity	1X3	1X6	1X3	1X6	1X2	1X2	1X2	1X4	1X2


Tag	Ⓐ	Ⓑ	Ⓒ	Ⓓ	Ⓔ	Ⓕ
Image	wheel 	spacers 	screw 	Assembling key 	bag 	bag hanger 
Quantity	1X4	1X12	1X16	1X1	1X4	1X8

Step 1


Connect "❻" & "❼" to "❺", then insert "❽" to "❻" & "❼"

❺ X2
❻ X2
❼ X2
❽ X4






Press button on unit "❻" to insert into the hole on the unit "❽"



Step 2

Use"Ⓒ"and the provided wrench, connect "❾" to ❽". Repeat this step for the other side of the frame.

Ⓒ X4
❽ X4
❾ X2




support@romoons.com

Step 3

Attach "❷" into each side of "❶".


❶X3
❷X6




Step 4

With spacers“Ⓑ”in between support “❷” and the frames from Step 2, use screws and secure with the wrench.

Ⓒ X2
Ⓑ X2
❷ X2






support@romoons.com

Step 5


Repeat Step 4 for the other side of the frame.



Step 6

Attach "❹" into each side of "❸".

❸X3
❹X6




support@romoons.com

Step 7

Using the provided wrench, use "Ⓒ" to attach "Ⓑ" to "❹" from step 6. Repeat this step for the other side of the frame.


Using the provided wrench, attach "Ⓐ" to "❽" from step 2 . Repeat this step for the other side of the frame.



Step 8

Slide "Ⓕ" into "Ⓔ". Repeat this step for the other side of the frame

ⒻX8
ⒺX4




support@romoons.com

Step 9

Place the Laundry Bags from Step 8 on the top Support Bars from Step 5.

Note: Make sure both Locking Wheels "Ⓐ"are on either the front or back side.



For any inquiry or customer service,please contact us, Romoon cousumer service is here to assist you.
E-mail:support@romoons.com

RoHS 

Made in China