






**SCAN CODE TO
SEE ASSEMBLY
INSTRUCTIONS,
MOPPING TIPS,
AND MORE!**

TO ASSEMBLE MOP



- 1 Screw the **bottom handle** into the **plastic connector sleeve** on the **top handle** and twist tight.



- 2 Place the **mop head** on the floor with **plastic ring** facing up. Align the **head base** over the **plastic ring** and tap with foot on the **head base** to click the **mop head** into position.



- 3 Gently lower the **locking lever** to release and lengthen the handle. **WARNING:** DO NOT lower past approximately 45° as that will damage the lever. Then raise the **locking lever** and snap back into place. You are ready to mop!



Questions or concerns? Call Libman at 877.818.3380.



WRINGING INSTRUCTIONS



1 Add any desired cleaning solution. Fill bucket with water to MAX WATER FILL line. DO NOT OVERFILL.




2 Dip mop head in water and soak thoroughly.



3 Place mop in the wringer basket, making sure to get all yarn strands inside.



4 Gently release locking lever. DO NOT lower past 45° as that will damage the lever. Push handle up and down to wring.



5 Extend handle and snap locking lever back into place. You are ready to mop!

MOPPING INSTRUCTIONS



1 Before mopping, place mop handle grip in between open palm hands and spin mop to flare out mop strands.



2 Mop in "S" shape, making sure no strands get caught under green mop head.



3 If any strands do get caught under green mop head, repeat Steps 1 and 2.



SCAN CODE TO SEE ASSEMBLY INSTRUCTIONS, MOPPING TIPS, AND MORE!

USE & CARE: Machine or hand wash mop head in warm, sudsy water and air dry. Do not use bleach or fabric softener.

Questions or concerns? Call Libman at 877.818.3380.