


Kepwaa Hand-Held Steamer




Please read this manual carefully before using the product and keep it properly.

After-sales Email: mxvipservice@outlook.com

Basic parameter

Product name: Hand-Held Steamer	Rated frequency: 60Hz
Product model: G9	Tank capacity: 70 mL
Rated voltage: 110~120V	Net weight of product: 1.2 lb
Rated power: 1200W	Product size: 10.4x2.8x2.7 inches

Structure description




After-sales Email: mxvipservice@outlook.com

Preparation before use

1. please open the tank cover upward and pour purified water or distilled water.




2. The angle of the ironing head can be adjusted in advance according to the usage habits. Do not rotate the ironing head during use, it will burn your hands. Please use it safely.



Note:

1. After power-on preheating: the temperature rises, please operate carefully; Do not touch the panel during ironing to avoid burns.
2. Press the switch button to start spraying steam, and then press the switch button to spring back without spraying steam.
3. After use, please turn off the switch button and unplug, and wait for the cooling panel to be put away.


Warning Every time you start using the steamer, keep the steam outlet facing downwards to prevent accidental water spray injuries.




After-sales Email: mxvipservice@outlook.com

Instructions for use


1. Hang clothes that need ironing on hangers or lay them flat.



2. Plug in the power supply, the indicator lights up, starts to preheat.




3. After about 15 seconds of preheating, the indicator light is off, and you can press the steam button to help ironing clothes. Note: If you press the steam button before the preheating is completed, water may be sprayed.



After-sales Email: mxvipservice@outlook.com

4. After turning on the steam, let the panel close to the folds of the clothes and move back and forth along the direction of the clothes fibers to make the clothes ironed evenly.



Flat iron



Hang iron

Warning Do not put clothes directly on the hard table to avoid damage to the table, and at the same time, moisture will gather on the clothes; It is recommended to place the clothes on the ironing board for flat ironing; During the flat ironing process, if you feel the steam temperature on the side, you can wear heat-insulating glove;



Use glove if the steam feels hot. Glove can worn on the hand holding the handle of the garment steamer to avoid scalding hands from the steam. The panel can be touched and rotated for a short period of time while wearing gloves.

Indicator light description

When the power is switched on:



Light on
Heating up



Light off
Keeping warm

After-sales Email: mxvipservice@outlook.com

Placement mode



Luggage



Bag

Precautions

1. This product is for indoor use only.
2. Please use 110~120V, 60Hz power supply to supply power to the product.
3. **Warning: Using it in Europe or other 220-240V areas will result the product broken.**
4. Because there are many impurities in tap water, long-term use will cause scales in the water tank and steam holes, and may stain clothing. Please try to use pure or distilled water for ironing.
5. Make sure to keep the plug dry; when the product is connected to the power supply, you must use dry hands to avoid contact electric accident.
6. When not in use, be sure to unplug and cut off the power supply.
7. If the power cord is damaged during use, in order to avoid danger, the manufacturer, its maintenance department or replacement of professionals in similar departments.
8. If the product fails to work, please contact our company in time and send it to the designated repair point for special inspection and maintenance by industry personnel.
9. Do not disassemble and repair by yourself, try to disassemble or change the structure of this product, so as not to cause unnecessary failures or dangerous.
10. Children under 10, elderly people or patients who have lost the ability to take care of themselves, please use this product under adult supervision product to prevent accidents.

After-sales Email: mxvipservice@outlook.com

11. When cleaning the stain on the appearance of the product, please wipe the product with a soft and clean cloth, such as in a water tank if the scale deposits, please clean it with professional supplies or ask a professional to clean it.
12. Do not use medical diluted alcohol, otherwise it may damage the product or erase various marks on the product.
13. When using appliances, pay attention to avoid the danger of steam splashing.
14. When filling and cleaning, the power plug should be unplugged.

Product list

Garment steamer*1 Manual*1 Flannel bag*1 Glove*1
Water Measuring cup*1

Warranty description

Warranty Policy

During the validity period of the after-sales service, you can enjoy the service of return, exchange, and replacement in accordance with these regulations. The relevant after-sales service should contact the customer service staff with the invoice or order record.

1. If the product fails with non-human factors during use, after inspection and verification, a free warranty service within one year from the date of sale will be provided;

2. After the expiration of the after-sales service period, maintenance services can still be obtained, but the related maintenance costs shall be borne.

Non-warranty Policy

1. Damage caused by failure to follow the instructions;
2. Unauthorized maintenance, misuse, abuse, alteration, incorrect use of this product and other man-made causes damage to the product or accessories; or tearing up or altering labels or anti-counterfeiting marks;
3. All man-made damage or damage caused by force majeure;
4. The after-sales service limited period has expired.

After-sales Email: mxvipservice@outlook.com

Kepwaa

After-sales Email: mxvipservice@outlook.com