



# QUICK START GUIDE


When using the appliance for the first time, remove the wraps and attach the parts by following the steps below.




Push the air circulator into the base by aligning the cutout on the bottom of the air circulator with the jutting point in the middle of the base.



Thread the screw through the flat washer, insert into the base, and use the included screwdriver to drive the screw into the bottom of the air circulator.



Put the air circulator upright, hold the main body while rotating the Adjustment Collar counterclockwise to raise or lower the air circulator to the desired height.



Tighten the adjustment collar by rotating clockwise. Plug the power adapter into the power (located at the back of the air circulator), and into the power outlet.



**CAUTION**

Do not operate the air circulator if the base has not been installed.