


CAPOXO



USER MANUAL

N7 True Wireless Earbuds

1 CUSTOMER SERVICE

✉ Email: service@capoxo.store

📞 Phone: (857) 887-2857 (Mon. - Fri., 11am - 8pm EDT)

🌐 Web: www.capoxo.store


2 PACKING LIST



Charging Case x1



Earbuds x1 Pair




Type-C Cable x1



User Manual x1

3 PRODUCT OVERVIEW



* Please kindly note that the wireless charging area is on the back of the charging case.


4 SPECIFICATIONS

- Model Name: N7
- Bluetooth Version: V5.3
- Support: AVRCP/HFP/HSP/A2DP/SBC/AAC
- Transmission Range: 33feet (without obstacle)
- Charging Time: about 2H
- Headphones Battery Capacity: 45mAh
- Charging Case Battery Capacity: 400mAh
- Charging Port: Type-C

5 CAUTION

- ① Please remove the protective film before use, otherwise the headphones will not be able to charge.

Tear off the protective film





② Wear correctly to enhance sound quality.



③ Please clean the charging contact on earbud and charging pin on the charging case with alcohol wipes if the headphones can't be charged.

* To fix charging issue

Charging Contact



Charging Pin

6

MULTI-FUNCTION OPERATIONS



Incoming Call

Answer

Press (L/R)
Earbud Once

End Call

Press (L/R)
Earbud Once

Reject Call

Press (L/R)
Earbud Twice

Voice Assistance

Note: in standby/ play mode











Siri



Press (L/R) Earbud Thrice



Music Mode

	Press (L/R) Earbud Once	
	Press (R) Earbud Twice	
	Press (L) Earbud Twice	
	Press & Hold (R) Earbud	
	Press & Hold (L) Earbud	

Note: 1 - Prompt sound "Du" will be produced when the volume reach minimum or maximum level.

2 - For Android user, please enable "Absolute Volume"/"Media Volume Sync" in your phone settings", otherwise the volume on headphones will not be synchronized with your Android phone. Scan this QR code to watch a video to learn more details.



CHARGING CASE

Battery indicator of Charging Case

The display will light up to show the remaining power of charging case when you open (or close) the lid, then go off after 8 secs. The number will flash when being charged, and will be "100" when fully charged and stay on until the power supply cut off.



Battery Indicator of Earbuds

Put the earbuds back into the box to charge the earbuds. The battery icons will flash when charging, will turn off after fully charged.

* Features with NTC tempera control protection, N7 earbuds will not charge if the temperature reaches 45 degrees or higher. (Charging case will automatically protect themselves in that case.) It is recommended to stop charging (or disconnect wireless charging) firstly, recharge after the temperature drops below 45 degrees.

Wireless Charging Supported

We recommend you to use wireless charging pad (not included) with Qi certificate.



POWER ON/OFF

Automatically Power On/Off

Open the lid of the charging case and the earbuds will power on automatically. Put the earbuds into the charging case and close the lid, the earbuds will power off automatically.



Manually Power On

Press & hold both earbuds for 2 secs, it will flash **Blue** light and then power on.



Manually Power Off

Press & hold either earbud for 5 secs, it will flash **Red** light and then power off. (Non music mode)



Note: The earbuds will automatically power off if there is no devices connected within 5 mins.


9 BLUETOOTH CONNECTION

Step 1

Open the lid of charging case, two earbuds will automatically power on and enter pairing mode.

Step 2

Activate Bluetooth setting on your phone, search and connect "N7".



10 SINGLE MODE

- When on dual mode, put one earbud into the charging case.
- Only take one earbud out of the charging case and connect it.



11 PAIR WITH OTHER DEVICE

N7 Wireless Earbuds have memory function, they usually auto connect with the last paired device.

Thus, if you want to pair them with other device, you should disconnect "N7" from the last paired device, AND forget the pairing record on the last device.

Then try to connect them to a new device, they should work properly.

FACTORY RESTORE SETTING



When should I reset?

When only one side play music.

When you can't use the two earbuds together.

When both earbuds fail to pair with each other or occur connection related issues.



How to reset?

- Delete all "N7" from the Bluetooth menu on your phones and deactivate the bluetooth setting.
- Press & hold either earbud for 5 secs, it will flash Red light and then power off.
- Press & hold both earbuds 8 secs simultaneously to clean the pairing record with the last paired device.
(* Both earbuds will flash Red & Blue light 3 secs, then turn to Red light and stay on for 1 sec then go off.)
- Put the earbuds back into charging case and close the lid.
- Now open the charging case and turn on the Bluetooth on your device, search and connect "N7", they should work properly.
(* If it still doesn't work, please repeat the steps to try again.)

FCC CAUTION

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Activate Warranty



Contact Us

Thank you for purchasing the authentic product. For more newer products, parts and accessories, please visit: www.capoxo.store
For any assistance please contact Email: service@capoxo.store

