

Thank you for purchasing the Living Color Lamp by Etekcity.

Light up your desk for work and studies while illuminating the environment with a full spectrum of color. Select between a single custom color and Color Cycle Mode to personalize the mood of your home decor. The lamp is fully adjustable, allowing you to set up the light at just the right angle. Rechargeable, simple, and easy to use, this dual function desk lamp is the ideal addition to any office space or room.

If you have any questions or concerns, please reach out to our helpful Customer Support Team at support@etekcity.com. We hope you enjoy your new living color lamp!

BECOME AN ETEKCITIZEN

Get exclusive deals, giveaways, and product registration. Better products for better living.

Find us at etekcity.com

Package Contents

- 1 x Living Color Lamp
- 1 x Micro USB Charging Cable
- 1 x Cleaning Cloth
- 1 x User Manual

Specifications

White Light	5000-5500K
Brightness	3 levels
Input	(Recommended) USB 5V / Max 2A Note: Do not use an adapter with an output voltage more than 8V.
Battery Capacity	1000mAh
Light Source	16 x 0.2W / LED
Operating Conditions	-4°-131°F / -20°-55°C

Safety Information


To reduce the risk of injury and/or damage to this lamp, please read and follow all instructions and safety guidelines in this manual.

- Recharge **only** with the appropriate charger type (see **Specifications**). A charger that is suitable for one type of battery may create a risk of fire when used with another battery. **Do not** use an adapter with an output voltage more than 8V.
- Do not** place near a heat source or in direct sunlight. Charging the battery while exposed to heat may damage the battery and increase the risk of fire. Exposing the battery to fire or excessive temperatures above 265°F / 130°C may cause an explosion.
- Do not** take apart, modify, or repair this lamp. To ensure product safety, have servicing performed by a qualified repair person using **only** identical replacement parts.
- Do not** use if the lamp or cord is damaged.
- Do not** use with wet hands or near liquid. Keep dry. Use in dry areas **only**.
- To reduce risk of fire or electric shock, avoid overloading electrical circuits.
- Household use **only**.

SAVE THESE INSTRUCTIONS

Function Diagram

- A.** Light
- B.** Neck
- C.** ON/OFF Touchpad
- D.** Living Color Ring
- E.** Base
- F.** Micro USB Charging Cable
- G.** Power Switch
- H.** Charging Indicator Light
- I.** Micro USB Charging Socket



Setup

- Place on a flat, stable surface.
- Before first use, charge for 2-3 hours using the included micro USB charging cable (see **Charging the Lamp**).

Controls

Power Switch

- Turns the power on/off.
- Keeping the main power switch "OFF" when not using will help save battery power.

ON/OFF Touchpad

- Tap to cycle through light settings: low, medium, high, and off.

Living Color Ring

- Tap on the Living Color Ring to turn on the living color base lighting. *[Figure 1.1]* Tap again to turn off.
- Tap any color on the Living Color Ring to select that lighting color for the base. You can also drag your finger around the Living Color Ring to choose a color.
- While the color is on, press and hold on the Living Color Ring for 3 seconds to turn on Color Cycle Mode.




Figure 1.1

Adjusting Lamp Position

- You can move the lamp neck to any desired position. *[Figure 1.2]*

Charging the Lamp

- When the lamp light dims to a lower level than usual, recharge the lamp using the included micro USB charging cable. The cable may be connected to any powered USB port for charging.
- You can use the lamp while charging. Turn off for faster charging.
- The charging indicator light will light up red while charging.
- When charging is complete, the light will turn green.

Cleaning the Lamp

- Clean with a soft, dry cloth.
- Do not** clean with any solvents or cleaning solutions.




Figure 1.2

Warranty Information

Product	Living Color Lamp
Model	S10A
Default Warranty Period	1 year
For your own reference, we strongly recommend that you record your order ID and date of purchase.	
Order ID	
Date of Purchase	

TERMS & POLICY

Etekcity Corporation warrants all products to be of the highest quality in material, craftsmanship, and service, effective from the date of purchase to the end of the warranty period.

Etekcity Corporation will replace any product found to be defective due to manufacturer flaws based on eligibility. Refunds are available within the first 30 days of purchase. Refunds are only available to the original purchaser of the product. This warranty extends only to personal use and does not extend to any product that has been used for commercial, rental, or any other use in which the product is not intended for. There are no warranties other than the warranties expressly set forth with each product.

This warranty is non-transferrable. Etekcity Corporation is not responsible in any way for any damages, losses, or inconveniences caused by equipment failure or by user negligence, abuse, or use noncompliant with the user manual or any additional safety or use warnings included in the product packaging and manual.

This warranty does not apply to the following:

- Damage due to abuse, accident, alteration, misuse, tampering, or vandalism.
- Improper or inadequate maintenance.
- Damage in return transit.
- Unsupervised use by children under 18 years of age.

Etekcity Corporation and its subsidiaries assume no liability for damage caused by the use of the product other than for its intended use or as instructed in the user manual. Some states do not allow this exclusion or limitation of incidental or consequential losses so the foregoing disclaimer may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

ALL EXPRESSED AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Additional 1-Year Warranty

You can extend your 1-year warranty by an additional year. Log onto www.etekcity.com/warranty to register your new product for the extended warranty.

Please fill out all required fields and include your order ID, place of purchase, and purchase date, if applicable.

Defective Products & Returns

If you discover your product is defective within the specified warranty period, please contact Customer Support via support@etekcity.com with a copy of your invoice and order ID. **DO NOT** dispose of your product before contacting us. Once our Customer Support Team has approved your request, please return the product with a copy of the invoice and order ID.

Customer Support

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

Customer Support

Etekcity Corporation

1202 N. Miller St., Suite A
Anaheim, CA 92806

Email: support@etekcity.com

Toll-Free: (855) 686-3835

Support Hours

Mon-Fri, 9:00 am-5:00 pm PST/PDT

**Please have your invoice and order ID ready before contacting Customer Support.*

Connect with us @Etekcity



Living Color Lamp

Model: S10A

User Manual

