

QUICKSTART GUIDE

SPARK 07




Please scan here to download a multi-language user manual

NOTES FOR MICROPHONE USE

- 1. Ensure the ear cups fully cover your ears. Incomplete sealing may weaken noise cancellation.
- 2. Keep the microphone 1-2 cm (two finger-widths) from your mouth during calls. Excessive distance reduces voice clarity.


Troubleshooting: Microphone Issues

- 1. Set as default: Input/output device → Spark 07
- 2. Enable mic: Confirm in device settings
- 3. Adjust position: Rotate mic to 1-2cm from mouth (two fingers)
- 4. Check mute: Disable mute in apps (e.g., Zoom, Teams)
- 5. Reset: Hold power button 8s until "beep".
- 6. Reduce interference: Avoid nearby wireless devices.



Bluetooth Pairing Issues


- 1. Turn off Bluetooth on other paired devices
- 2. Remove old devices from Bluetooth list
- 3. Check battery level and charge if low
- 4. Test connection with a different device
- 5. Reset: Hold power button for 8s until beep
- 6. Provide details: Device model & video for support



SPARK 07 CONNECTION GUIDE

1. Wireless Transmitter Mode

- a. Press and hold the power button for 5 seconds until the blue light stays on.
- b. Insert the transmitter into your device (ensure the blue light is on and the USB-C adapter is fully plugged in).
- c. Select "Spark 07" as the output device in your computer's sound settings.




Note:

When using the USB-A dongle, ensure the USB-C adapter is fully inserted to activate the signal control chip.

2. Bluetooth Mode

- a. Double-click the power button to enter Bluetooth mode (blue light flashes).
- b. Select "Spark 07" from your phone/computer's Bluetooth list to pair.



3. Wired Connection

- a. Connect the device to the headset using the 3.5mm audio cable.
- b. Navigate to the device's sound settings → Input/Output → Set "Spark 07" as the default device → Confirm.

