








SW Series
LCD Monitor
Quick Start Guide

DN: SW00-Q-V4

© 2018 BenQ Corporation. All rights reserved. Rights of modification reserved.



Factory Calibration Report

OSD Controller







USB

DP to mini DP


DVI-DL

8 Video


9 Audio




10




11





12




13



14




1



M4 x 10 mm


2




How to install the shading hood (optional step)




1




2




3



4




5





6




7




8




1




2




3



4



5



Palette Master Element



www.BenQ.com > SW2700PT Product Page > Download / Support



www.BenQ.com