

LOOSAFE

Solar Battery Outdoor Security Camera

Quick Start Guide

If you have any questions in the use of our product, contact us in following ways:

Email: support@loosafehome.com

Facebook: www.facebook.com/loosafehome

Instagram: @loosafehome


Twitter: @loosafehome

WhatsApp: +1 (678) 861-1033


Or call us on: +1 (678) 861-1033

All questions will be answered in 24 hours. Thank you.

CAMERA OVERVIEW




LOOSAFEHOME



Speaker

Micro SD Card, Reset Button Inside



Micro SD Card Slot

Reset Button

CHARGING THE BATTERY



Charging Port
Charging Indicator

For the [1st use](#), please charge the solar battery with a [5V2A](#) adapter for more than [10 hours](#).

Tips: A smaller charger can't charge the battery.

The [green light](#) flashes while charging, and remains on after charging.




The [red light](#) flashes on the solar panel when there is less power in the battery.

GET THE APP




Download and install the "[UBox](#)" app from App Store or Google Play. Simply search for "[UBox](#)".

FIEST TIME SETUP




Launch the UBox app. Create an account or log in if you already have an account. Follow the steps to create a family.

INSTALL STORAGE CARD



Open the camera's gate with a screw, then insert a [micro SD card](#) when the camera is off. Support TF card up to [128GB](#) with FAT32 format.

POWER ON THE CAMERA



Attach the connectors **tightly** (for water proof), one is from the camera and the other from the solar panel.




Put the switcher to the “**ON**” part.

CONNECT CAMERA TO YOUR PHONE



After powering on the camera, wait until the indicator flashes **blue light**. Then you will hear a notification, "The camera is now ready to begin pairing." The camera goes to pairing model. Before pairing, please make sure that your phone connects to the **2.4Ghz** WiFi network. And has your WiFi password ready. Tips: Make sure your phone **didn't connect a 5Ghz WiFi**.

ADD A DEVICE



Follow the steps on the app to add a device.

INPUT WiFi PASSWORD



The app will input your phone's WiFi connection name and you only need to input the password.
Tips: Make sure your phone connect to a 2.4Ghz WiFi and the WiFi name is in English. It doesn't support 5Ghz WiFi and WiFi name in other language.


QR CODE CONFIGURATION



Then choose [QR code configuration](#) or Sound wave configuration. Tips: if the camera can't connect through QR code, please try Sound wave method.

Checking the camera is ready to begin pairing (Indicator flashes blue light). If not, please [RESET](#) the camera by press the RESET button in the camera for more than 5 seconds until you hear the "RESERTTING" sound.


VIEW ON YOUR PHONE



Go to the “Device” page and click on the device to view.

CAMERA INSTALLATION TIPS

Assemble Height and Detection Area



We suggest you to install the camera at a height about **10 FT**, it will have the best detection distance. And to fix the camera to focus on the main areas you want to monitor.

LOOSAFEHOME

If you have any questions in the use of our product, contact us in following ways:

Email: support@loosafehome.com

Facebook: www.facebook.com/loosafehome

Instagram: @loosafehome

Twitter: @loosafehome

WhatsApp: +1 (678) 861-1033

Or call us on: +1 (678) 861-1033

All questions will be answered in 24 hours. Thank you.