S6 USER'S GUIDE



TRIPLE SCREEN

LAPTOP SCREEN EXTENDER

Friendly Reminders:

1. Ensure a secure connection of the Type-C data cable to the device interface.
2. This product seamlessly supports all Type-C functions, including charging and video, through a single integrated cable. In the event of screen power issues or restart difficulties, kindly provide external power of 5V, 2A.
3. When using the PD interface to connect the product, please use the HDMI To TYPE-C data cable included in the package and ensure external power is supplied.

Windows Mac Android

Product Introduction

S6 is a versatile plug-and-play dual-screen laptop monitor that's not only portable and foldable but also a quick ticket to your own on-the-go mobile studio. It's the perfect solution for laptop users looking for multi-screen sync or separate displays, boosting your work efficiency by up to 50% for some serious multitasking mojo. It's got the chops to sync up with models from Samsung, Huawei, and more. Plus, it's game for smartphone system computer mode, audio/video transmission—you name it.

The S6 stand is very simple to use. Just place it on your desk, next to your laptop screen, open the support stand, open the rotating arm, install the left and right screens into the stand, and the product installation is complete. The stand supports extension and can accommodate laptops of all sizes.The screen supports horizontal and vertical display, with the angle adjustable from 0 to 90 degrees, suitable for various usage scenarios. Whether you are a professional, office worker, gamer, entrepreneur, programmer, student, or stock trader, you can easily get started and enjoy a unique entertainment experience.

The S6 screen supports the adjustment of brightness, sound, contrast, and other parameters, and is equipped with a TYPE-C/USB C with DP interface. It can perform multifunctional video extension. As long as it is a TYPE-C laptop with signal + power combination, single-line connection display can be achieved. Devices such as desktop hosts/laptops/miniPCs/game consoles with HDMI output interfaces can be directly connected for display, but the screen needs an external power source to light up.

The S6 screen supports vertical rotation of 0-90 degrees and horizontal folding of 0-235 degrees.

It also supports various screen combination modes. You can choose the best viewing angle for you, providing the most outstanding visual experience.

Contents of Instruction

Product Attributes

1. Product host 1
2. Accessories 1
3. Parameters 1

Installation and Storage

1. Opening Method of the Stand 2
2. Screen Installation Method 2
3. Single Screen Stand Installation 3
4. The states of the screen and stand combination 3
5. Storage 7

Key Definitions 8

Connection Mode

1. Connect S6 with Laptop 9
2. Device power supply connection mode 9

Audio Settings

1. Change sound settings of Windows 10 / Windows 11 10
2. Change sound settings of MAC OS PC 11


Display Mode

1. Windows 10 / Windows 11 Display Settings 12
2. MacOS 13 Ventura Display Settings 13

Transportation, Storage and Safety Information 14


Product Attributes


1. Product host





2. Accessories


S6


USB-A to USB-C *2


USB-C to USB-C *2


HDMI to TYPE-C


BAG


Sleeve Stand


Single Screen Stand


3. Parameters

Weight:	2.39 Kg	Screen Size:	15.6 Inches
Aspect Ratio:	16:9	Panel Type:	IPS Wide Viewing Angle
Size:	360.7x216.6x45mm	Average Brightness:	300CD/M^2
Refresh Rate:	60Hz	Type-C Input:	5V-20V / 5A Max
Resolution:	1920x1080 P	Type-C Output:	5V-20V / 4.25A Max
Speakers:	2	Ports:	TYPE-C*2+USB C with DP


Installation and Storage

1. Opening Method of the Stand


Step1: Separate the screen from the stand.




Step2: Expand the stand.



2. Screen Installation Method




Assemble the screen stand
(pay attention to the left and right screen labels).




*Note:Open the stand, adjust it to the appropriate supporting angle, place it behind the computer screen,and complete the installation of the dual-screen support.

Installation and Storage

3.Single Screen Stand Installation




Install the single screen stand.



The single screen stand supports 360-degree rotation.


4.The states of the screen and stand combination




When rotating the screen, the screen and the stand must be parallel to avoid scratching.




Landscape Display



Portrait Display




Portrait & Landscape Mode




Detached Mode

Installation and Storage

Dual Screen Horizontal State







When in use, opening the support plate and making it contact with the sleeve stand can provide a triangular support force.

①: Open the movable arms of the left and right stands.
②: Open the support plate.
③: Install the sleeve stand into the right stand's movable arm.
④: Install the single screen stand into the sleeve stand.
⑤: Install the right screen into the L screen stand's movable arm (for horizontal display).
⑥: Install the left screen into the single screen stand, rotate 180 degrees to complete the installation.

*Note: When connecting to the computer, the left screen needs to be flipped horizontally by 180 degrees in the display settings.

Dual Screen Horizontal and Vertical State






①: Open the movable arms of the left and right stands.
②: Open the support plate.
③: Install the sleeve stand into the right stand's movable arm.
④: Install the single screen stand into the sleeve stand.
⑤: Install the right screen into the L screen stand's movable arm (for horizontal display).
⑥: Install the left screen into the single screen stand, rotate 90 degrees to complete the installation.

*Note: When connecting to the computer, the left screen needs to be rotated horizontally by 90 degrees in the display settings.


Installation and Storage

Dual Screen Horizontal and Vertical State




①: Open the movable arms of the left and right stands.
②: Install the sleeve stand into the right stand's movable arm.
③: Install the single screen stand into the sleeve stand.
④: Install the right screen into the L screen stand's movable arm (for Vertical display).
⑤: Install the left screen into the single screen stand, rotate 180 degrees to complete the installation.

Dual Screen Front and Back Horizontal State



①: Open the movable arms of the left and right stands.
②: Install the right screen into the L screen stand's movable arm (for horizontal display).
③: Install the left screen into the R screen stand's movable arm to complete the installation.


Dual Screen Front and Back Vertical State



①: Open the movable arms of the left and right stands.
②: Install the right screen into the L screen stand's movable arm (for Vertical display).
③: Install the left screen into the R screen stand's movable arm to complete the installation.


Installation and Storage

Dual Screen Horizontal and Vertical State



①: Open the movable arms of the left and right stands.
②: Install the sleeve stand into the right stand's movable arm.
③: Install the single screen stand into the sleeve stand.
④: Install the right screen into the L screen stand's movable arm (for horizontal display).
⑤: Install the left screen into the single screen stand, rotate 90 degrees to complete the installation.

Dual Screen Front and Back Horizontal and Vertical State




①: Open the movable arms of the left and right stands.
②: Install the sleeve stand into the right stand's movable arm.
③: Install the single screen stand into the sleeve stand.
④: Install the right screen into the L screen stand's movable arm (for horizontal display).
⑤: Install the left screen into the single screen stand, rotate 90 degrees to complete the installation.


More stand combination modes and ways of use await your exploration.

5.Storage

Step1: Remove the left and right screens.




Step2: Fold up the stand.



Step3: Combined storage the screen and stand


*Note: The right screen's silicone should align with the left screen's limit hole for combined storage.




Combined storage the screen and stand.




*Note: The screen's protruding part should align with the stand's groove for storage.



Storage in the leather case.




Key Definitions




Connection Mode

1. Connect S6 with Laptop

TYPE-C Connection:
If your laptop has two full-featured Type-C ports, you can connect the S6 directly to your laptop with two Type-C cables.



TYPE-C & HDMI & USB-A Connection:
If your laptop has one full-featured Type-c port, one USB-A port and one HDMI port, please first connect one monitor using the USB-C cable. Then connect the other monitor using the USB-A to USB-C cable and the HDMI to Type-C cable.



Notice:
If the display has no signal or the signal is unstable after connection, please connect an external 5V/2A power adapter to power the laptop

2. Connect S6 with Mobile Phone with Other Devices



Switch connection mode
(External power suply required)

Mobile phone connection mode
(External power supply required)

Audio Settings

1. Change sound settings of Windows 10 / Windows 11

1.1 Right click the loudspeaker icon located in the bottom-right corner.




1.2 Select "switch on sound " in pop-up dialog box

1.3 Left click "turn on sound settings" and pop-up the box as provided, here users can set about sound

Here users can set about sound

1. Master volume;
2. Select output device: (S6 / Speaker);
3. Device attributes.




2. Change sound settings of MAC OS PC

2.1. Choose Apple menu > System Settings




2.2. Click "Output", then select the device you want use for the list of sound output devices: [S6 / Speaker]



Display Mode

1. Windows 10 / Windows 11 Display Settings

1.1 Right-click a blank area of the desktop. Select 'Display Settings' from the pop-up dialogue box. Left click "Display Settings" to open the settings dialogue box, shown in the figure:



1.2 Under the "Rearrange displays" section, drag and drop each display to rearrange them according to their physical layout of your desktop. Scroll down to the bottom of the page to further configure the display for extended or mirrored mode.

NOTE: When installing vertically, the display direction needs to be rotated (right screen 270 degrees, left screen 90 degrees) in the computer display settings.

2. MacOS 13 Ventura Display Settings

2.1 Enter the "System Preferences" menu



2.2 Configure your monitor

In this menu, you can set the resolution and mirror/extend the display you want.



2.3 Arrange Displays

To rearrange displays, drag them to the desired position.
To mirror displays, hold Option key while dragging them on top of each other.
To relocate the menu bar, drag it to a different display.



Transportation, Storage And Safety Information

To ensure the safe and proper usage of this product and to prevent potential accidents such as electric shock or fire, it is essential to thoroughly read and comprehend all usage requirements and operational procedures before utilizing it. Kindly adhere strictly to the following guidelines:

1. Before use, kindly remove the protective film covering the screen surface.
2. The DC power supply required for this product is an AC/DC power adapter. Ensure it is positioned far away from heat sources and placed in a well-ventilated area. The AC power socket and AC power line must be properly grounded and capable of handling the necessary current demand.
3. The DC power input required for this product is 5V-20V±2V.
4. Take care to prevent excessive humidity and dust accumulation to avoid circuit corrosion and potential failures.
5. Avoid subjecting the screen to external forces.
6. Refrain from using sharp tools that may damage the screen.
7. This product is suitable for general business and domestic use, with a recommended ambient temperature ranging from -20°C to 60°C.
8. Remember to power off the device when not in use.