



PEAKEEP

4" Twin Bell Alarm Clock





Tips

1. Please do follow the arrow to turn the knob for settings, or the quartz movement will be damaged or inaccurate.

2. Rechargeable and used battery is not recommended. Generally, the voltage of rechargeable battery is 1.0V---1.42v, the normal operating voltage of this item is $\geq 1.42V$. Therefore if rechargeable battery or used battery is inserted, clock will not run correctly few days later due to the low voltage.

3. Do not pull the knobs out, which may cause

damage to this unit.

4. Dropping may cause damage, use with caution!

Power On

Open the battery cover, insert one new AA (1.5V) non-rechargeable battery according to the cathode and anode, replace cover.

Setting the Clock Time

According to the direction of the arrow  to set time with time knob.

Setting the Alarm

According to the direction of the arrow  to set wake up time with alarm knob. There're four small lines between each hour. For the alarm, they indicate 12 minutes each, for clock time, they indicate 1 minute each.

Turning the Alarm On/Off

Turn the alarm switch  to "ON", the alarm will go off at the time you set and last for approximately 50 minutes. Turn the alarm switch  to "OFF" to turn off the alarm.

Temporary Blacklight Function

At night, press and hold the light button , time will

be clearly visible.

Replacing Battery

When time runs with deviation or ringing sound becomes very low, please replace the battery.

Troubleshooting

1. Clock Does Not Keep Time

If the clock does not keep time, please try to turn the time and alarm knobs following the arrows several times to see if the clock will work fine or not. One possible case is that the hands were just stiff and got stuck.

2. Alarm Accuracy

It's not going to be digital precision on all this type of analog alarm clocks. Generally the alarm is ± 5 minutes against the setting time.

Customer service

We strive for excellent customer service. Any reason unsatisfied, refer to our warranty card, feel free to contact us at:

 [**sales@us-myehome.com**](mailto:sales@us-myehome.com)

first, there'll be delightful communication and good solution. Our service is always open for you, problems never remained.