



HEATED THROW

Get the most from your
Slumberdown Heated Throw

We know you can't wait to plug in your Slumberdown Heated Throw. But give this booklet a quick read first.

It outlines some important information about safety, care and cleaning that will help you get years and years of comfort and warmth.

At the back, you'll also find details of your Guarantee and our Customer Helpline. So it's probably a good idea to keep this booklet in a safe place, in case you need to refer back to it later.

Contents

Safety Instructions	Page 3
Read and follow these instructions carefully	
Using your Heated Throw	Page 4
Operating instructions for the hand control	
Using your Heated Throw	Page 5
Getting your appliance to the right temperature	
Cleaning and Care	Page 6
Instructions for washing, drying and caring for your throw	
24-month Guarantee and Customer Helpline	Page 7
What to do in the unlikely event that your throw is faulty	

Safety Instructions

PLEASE KEEP THESE INSTRUCTIONS SOMEWHERE SAFE, SO YOU CAN REFER BACK TO THEM.

Using your appliance


- This appliance must be used only for the purpose for which it was designed for, for home use. Any other use is considered not compliant with the intended use and therefore dangerous.
- After unpacking your Slumberdown electrical appliance, please make sure that it is intact with no sign of damage. If in any doubt, do not use the appliance and contact the retailer that you purchased the appliance from.
- Before connecting the appliance to the mains supply, make sure that the voltage and frequency indicated on the technical data of the appliance correspond to those of the mains supply. The rating is on the appliance or on the power supply unit.
- This appliance is only to be used with the types of detachable control EN unit that are marked on the appliance.
- Children **under the age of 3 should not use** the heated appliance due to their inability to react to overheating.
- **Children under 8** should only use the appliance if they're supervised by an adult with the control always set to minimum temperature (recommended as heat setting 1).
- **Children aged 8 years and above or people with reduced physical, sensory or mental capabilities or lack of experience and knowledge** can use the appliance if they've been given supervision or instruction on how to use it safely. Children should always be supervised until they're mature enough to understand how to operate it safely and understand the hazards involved. Cleaning and user maintenance must not be carried out by children without supervision.
- The heated throw shouldn't be used by persons insensitive to heat and other very vulnerable persons who are unable to react to overheating.
- This appliance can give rise to the risks of entanglement, strangulation, tripping or treading if not safely arranged. Keep cords out of reach of young children and securely and safely out of the way.
- Always disconnect the appliance from the mains supply before cleaning or performing maintenance and when the appliance is not in use.
- Regularly examine the appliance for signs of wear or damage. If the appliance has been misused or does not work, contact the retailer that you purchased the appliance from before switching it on again.
- If the supply cord is damaged, take the whole appliance to an authorised technical service centre for the replacement of the control unit, to prevent all risks.
- If the appliance is used on an adjustable bed, check that the throw and cord do not become trapped or rucked, for example in hinges.
- This appliance is not intended for medical use in hospitals.

Looking after your throw

- **DO NOT** insert pins or needles.
- **DO NOT** use if wet.
- When storing the appliance, allow it to cool down before folding.
- **WARNING! DO NOT** crease the appliance by placing items on top of it during storage.
WARNING! For use, cleaning, maintenance, and storage of the appliance, please follow the instructions specified in the corresponding chapters.
- **DO NOT** use the appliance with wet hands or damp feet.
- **DO NOT** pull the power cable or the appliance itself to remove the plug from the socket.
- **DO NOT** pull or lift the appliance by the supply cord.
- If the appliance is faulty or malfunctions, switch it off and do not tamper with it. Contact an authorised technical service centre for any repairs.
- **DO NOT** use this appliance to warm animals.
- **DO NOT** tuck in.

Using your Heated Throw

1. Open the heated throw out fully to check for any damage before spreading it out over your sofa, armchair or bed ensuring that the throw connector is at the foot position.
2. Connect the mains lead to the heated throw's socket. **See pic. A.**
3. Place the throw over you without wrapping it tightly and without sitting on it as this may cause the overheat protection system to activate.



Getting your appliance to the right temperature

1. Start by sliding the switch from 0 to 1 to turn the appliance on. **See pic. 1.**
2. Then use the hand control to choose from 9 warmth settings. **See pic. 2.**
3. Press the Temp button until you reach your desired heat setting
4. Setting 1 is the lowest heat setting and setting 9 is the highest heat setting.

The appliance will automatically set the heat to 0 when it's turned on.

Setting the time length.



The appliance has an automatic shut off timer for 1 to 9 hours and 12 hours.

1. Press the Timer button until you reach your desired time setting.
2. Setting 1 means that the appliance will automatically switch off after 1 hour, 9 means it will switch off after 9 hours and H means it will automatically switch off after 12 hours.

The appliance will automatically set the timer to 1 when it's turned on.

IMPORTANT: Ensure that the throw is draped over you to judge the temperature accurately, do not rely on a hand placed on the throw.

NOTE: For continuous use, set the control unit to temperature levels from 1 to 3 only.



Cleaning and Care

Here are some hints and tips that will help you get the best out of your heated throw for years to come.

WARNING! Always disconnect the appliance from the mains and disconnect the control connector from the throw before cleaning or performing maintenance.

Washing your heated throw

Your Slumberdown heated throw can be washed by hand or in the washing machine on a 40° wool cycle.

To hand wash

Fill a large bowl or a bath with warm water and mild detergent or washing powder. Leave the throw to soak for 5 or so minutes, then gently wash. Rinse in clean water until the water runs clear.

To machine wash

Pop your throw in the washing machine on a 40° wool cycle. Once your throw is washed, don't wring it out. Gently, but firmly, squeeze as much excess water out as you can.

Pre-treat any stains by spot cleaning before placing in the washing machine.

Use only the delicate cycle for spinning. DO NOT make an additional spinning cycle.

Drying your heated throw

The best place to dry your heated throw is on the washing line. Gently reshape it while it's damp, then hang it up, being careful not to peg any wired areas. Make sure it's completely dry before you use it.

Do not iron the throw.

Wear and tear checks

- Make sure the plug, mains lead, heated throw socket and controller remain undamaged, with no bare wire showing.
- Make sure the wiring of the heated throw isn't sticking out of the fabric anywhere.
- If there are signs of wear or damage, if the throw has been misused or doesn't work, contact the retailer that you purchased the throw from before switching it on again.

Storing the throw

Make sure that the throw has cooled down and then roll or loosely fold it up. Don't fold it too tightly or put heavy things on top of it, as it could damage the wiring.

If the throw has been washed, make sure that it is completely dry before folding it and storing it away.

You are advised to store the heated throw in the original packaging that it was supplied in where possible.

Make sure that the throw is stored in a dry place.

24-month Guarantee

This heated throw was individually tested before leaving our factory and should reach you in perfect working order.

- **If a fault develops within 28 days of purchase**, please accept our apologies and return it to the retailer you bought it from for a replacement. Don't forget to take your receipt along with you.
- **If a fault develops within 24 months of purchase**, please call the Customer Helpline at the bottom of this page. They'll ask you for the information below, so it would be a good idea to fill in your throw's details here. Hold on to your receipt too as proof of purchase.

Date of purchase
Place of purchase
Model Number
Controller Number

The terms of our guarantee

- This heated throw is designed for domestic/personal use only – this guarantee does not cover use in industrial/hospitality settings.
- Slumberdown will not be liable to replace the heated throw if:
 - The user hasn't operated and cared for it in accordance with the instructions in this leaflet.
 - The fault is a result of misuse or negligence – whether accidental or deliberate.
 - The heated throw has been used on the wrong power voltage supply.
 - The heated throw has been tampered with by someone who isn't qualified.
- Slumberdown will not be liable for any indirect or consequential loss or damage as a result of a fault on your heated throw unit.

This guarantee does not affect your statutory rights, and it does not give any additional rights other than those outlined.



Customer Helpline

+44 (0) 1924 483 276

Slumberdown, Nunbrook Mills, Mirfield, West Yorkshire, WF14 0EH



To view our full range visit
slumberdown.co.uk