X-GO
Quick-Start Guide

PORTABLE BLUETOOTH SPEAKER



Button Controls



	Power On/Off	Press and hold for 2 seconds
	Volume Up	Short press
	Volume Down	Short press
	Next Track	Long press
	Previous Track	Long press
	Play/Pause	Short press
	Enable/Disable Colorful Light	Short press
	Answer/End A Call	Short press
	Reject A Call	Double Click

Power Indicator



indicator		state	condition
	red light	on	During charging
		turns off	Fully charged
	blue light	flash slow	Bluetooth paired
		flash fast	Awaiting Bluetooth pairing
		stays on	TWS mode paired

Specifications

Specifications are subject to change without notice.

Input	5V⎓1A
Range	33ft/10m
Waterproof Rating	IPX5
Size	20.00×7.00×7.15cm/ 7.87×2.81×2.75inch
Net Weight	1.05lb/16.76oz/475g

Bluetooth Pairing



» 1. Bluetooth indicator flashes blue quickly indicating the speaker is waiting for pairing.
» 2. Open the Bluetooth Setting on your cellphone/device, search and select X-GO to pair.
» 3. Bluetooth indicator will flash blue slowly after paired.



» When turned on, X-GO will automatically connect to the last connected device if available.
If not, X-GO will enter pairing mode.

Connecting a non-Bluetooth audio device with the 3.5mm cable (AUX cable not included)

» 1. Make sure your X-GO battery has enough power and turn on the Bluetooth speaker.
» 2. Plug one end of the cable into your device's headphone jack and the blue light becomes staying on Insert the other end into X-GO.
» 3. Turn on your X-GO Bluetooth speaker and you can start playing music.
Note: When the audio cable is plugged into the speaker, the Bluetooth function will not be available.

Reset Your Speaker

(If your speaker is stuck)
Step 1: Remove the charging cable and 3.5mm audio cable, if connected.
Step 2: Press and hold power button for 8 second, then release the power button.
Step 3: The speaker has now been reset and you can turn it on.

Wireless Hands-free Phone Call Function

Hands-free functions are only available for Bluetooth-enabled smartphones.
Short press ⏯ button to answer an incoming call.
Short press again to end the call.
Double-click the ⏯ button to reject an incoming call.

CHARGING

1. Fully dry off the speaker and the USB port before charging.
2. Unplug the USB charging cable when it is not in use. Must seal the charging port when not charging to prevent water from entering!
3. The battery may go to sleep or die if it doesn't charge/discharge for a long time. Please charge and discharge it at least one time per month.

Pairing two speakers to create a stereo pair (TWS mode)

You can pair two X-GO together to create left and right channels and enjoy stereo sound.
» 1. Turn on both speakers. Their light bar will flash, indicating they are ready to pair.
» 2. Press and hold the ⏯ button of one speaker until you hear a beep, then you will hear a prompt tone, indicating the two speakers are paired successfully. Do not turn on your phone's Bluetooth function before the pairing is successful.
» 3. Turn on your device's Bluetooth and tap "X-GO", it will automatically connect one of the speakers.
When the pairing is completed, you can enjoy wireless stereo sound from both speakers.
Note:
» 1. Before pairing two speakers together, please make sure that the two speakers are not connected to other devices via Bluetooth. If one of them is connected to another device, they will fail to pair with each other.
» 2. Please note that both speakers can control the volume.
» 3. For a better listening experience, please put the speakers within 50 feet of each other. To achieve the best result, place the speakers in an open area without barriers.

Technical Update Notice:
To enhance connection stability and audio quality, our TWS pairing technology has undergone a significant upgrade. As a result, **older** and **newer versions** of the speaker are **not compatible for TWS pairing**. We are very sorry for any inconvenience this may cause and appreciate your understanding. For a TWS setup, please use version-matched units. If you need further assistance, **please contact our customer support**.

What's Included	Portable Bluetooth Speaker.....x1	Type C Charging Cable.....x1
	Portable Rope.....x1	Quick-Start Guide.....x1

Important Safety Instructions

1.Read and keep these instructions. Heed all warnings and follow all instructions.
2.Warning (if applicable): Please refer to any important information (e.g., electrical, safety, etc.) printed on the exterior bottom enclosure or rear panel before installing or operating the product.
Important Safety Information
3.Clean only with dry cloth
4.Water and Moisture (if applicable): Do not use this apparatus near water. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus. Electrical equipment should NEVER be kept or stored in damp environments
5.(If applicable) Do not block any ventilation openings. Install an accordance with the manufacturer's instructions. Do not install this equipment in a confined or "boxed-in" space such as a bookcase or similar unit, and maintain good ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, tablecloths, curtains, etc.
6.Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not place exposed flame sources such as lighted candles on the apparatus
7.(If applicable) This product should be connected to a power supply only of the type described in these operating instructions, or as marked on the unit
8.(If applicable) Be careful not to damage the power cord. When moving or not using the appliance, secure the power cord (e.g., wrap it with a cable tie). Before using it again, make sure the power cord has not been damaged. If the power cord has been damaged at all, bring the unit and cord to a qualified service technician for repair or replacement as specified by the manufacturer.
9.(If applicable) Be careful not to damage the power cord. When moving or not using the appliance, secure the power cord (e.g., wrap it with a cable tie). Before using it again, make sure the power cord has not been damaged. If the power cord has been damaged at all, bring the unit and cord to a qualified service technician for repair or replacement as specified by the manufacturer.
10. Unplug this apparatus during lightning storms or when unused for long periods of time.
11. Do not casually use inferior accessories that do not meet the electrical requirements of the device
12.Internal/External Voltage Selectors (if applicable): Internal or external voltage selector switches, if any, should only be reset and re-equipped with a proper plug for alternative voltage by a qualified service technician. Do not attempt to alter this yourself.
13.Additional Battery Warning (if applicable): Replacement of a battery with an incorrect type may defeat a safeguard; disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, may result in an explosion! Leaving a battery in an extremely high temperature surrounding environment, such as sunshine, fire, or a hot surface, may result in an explosion or the leakage of flammable liquid or gas. A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Risk of fire or explosion if the battery is replaced by an incorrect type!
14.(If applicable) Do not defeat the safety purpose of the polarized or grounding-type plug.
15.Protective earthing terminal (if applicable): The apparatus should be connected to a mains socket outlet with a protective earthing connection.
16.For Class II apparatus only: This symbol means the equipment is a Class II or double-insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth. When servicing use only identical replacement parts installed by an instructed person or with the use of ready-made leads or cords.
17.Warning (if applicable): Provide an earthing connection before the mains plug is connected to the mains. When disconnecting the earthing connection, be sure to disconnect it after pulling the mains plug out from the mains.
18.(If applicable) Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
19.Warning (if applicable): To prevent possible hearing damage, do not listen at high volume levels for long periods.
20.This apparatus is for professional use only. Intended operational climate: moderate.

Important Tips

1. **Environment and temperature**
Operating temperature should be between 0℃ to 40 ℃ / 32℉ To 104℉.
Keep away from extreme temperature environments (such as high temperature fire, direct sunlight or extremely cold environment) to avoid battery damage.
Do not approach heat sources (such as stoves, engines and other heating equipment).
2. **Use and maintenance**
Do not drop, disassemble or replace the battery (wrong model may cause explosion risk).
Do not use corrosive detergents/oils to wipe the product.
Keep away from water or humid environments (such as rainy days) when charging to prevent electric shock.

Notice

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.

Safety Notices

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE ANY COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL ONLY.

CAUTION! Risk of electric shock.Do not open.

DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol within the equilateral triangle is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

INSTRUCTIONS: The exclamation point within the equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this appliance.

CAUTION (for U.S.A. & CANADIAN models only): TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.
6: **NOTICE CONCERNING LASER PRODUCTS**: DANGER: INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCK FAILED OR DEFEATED. AVOID DIRECT EXPOSURE TO BEAM. USE OF CONTROLS OR ADJUSTMENTS OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.
7: **NOTICE CONCERNING FCC REGULATIONS**: You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (**a**) reorient or relocate the receiving antenna; (**b**) move this unit; (**c**) increase the separation between the equipment and receiver; (**d**) connect the equipment into an outlet on a circuit different from that to which the receiver is connected; (**e**) be sure that all cables are properly shielded, using a choke or ferrite where appropriate; or (**f**) consult the dealer or an experienced radio/television technician for help.
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (**1**) this device may not cause harmful interference, and (**2**) this device must accept any interference received, including interference that may cause undesired operation.
8: **RF Warning Statement**: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Avoid using this device in a high RF-radiated environment.
9: **For Canadian models**: This device contains licence-exempt transmitter(**s**)/receiver(**s**) that comply with Innovation, Science and Economic Development (**ISED**) Canada's licence-exempt RSS(**s**). Operation is subject to the following two conditions: (**1**) this device may not cause interference, and (**2**) this device must accept any interference, including interference that may cause undesired operation of the device. Under ISED regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by ISED. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by ISED to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device. This unit does not exceed the Class B limits for radio noise emission from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications. This device operates on a no-protection, no-interference basis. Should the user seek to obtain protection from other radio services operating in the same TV bands, a radio licence is required. For further details, consult Innovation, Science and Economic Development Canada's document Client Procedures Circular CPC-2-1-28, Voluntary Licensing of Licence-Exempt Low-Power Radio Apparatus in the TV Bands.
10:**For wireless products supporting the 5.15-5.35 GHz frequency band** (if applicable): Usage of the 5.15-5.35 GHz band are restricted to indoor operation only. This applies to the following countries: **AT, BE, BG, CZ, DK, EE, FR, DE, IS, IE, IT, EL, ES, CY, LV, LI, LT, LU, HU, MT, NL, NO, PL, PT, RO, SI, SK, TR, FI, SE, CH, UK, HR.**
11 :For 240-volt use in U.K., use NEMA*-style 240-volt plug. For other countries use proper plug for local outlet.

ESD/EFT Warning: This unit may contain a microcomputer for signal processing and control functions. In very rare situations, severe interference, noise from an external source, or static electricity may cause it to lock up. In the unlikely event that this should happen, turn off the unit, wait at least five seconds, and then turn it back on again. The pins of connectors identified with this ESD warning symbol should not be touched.
13:**If the product or remote control contains a button cell or coin battery** (CR1220, CR2025, or CR2032; 3.0 VDC):

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- KEEP new and used batteries **OUT OF REACH of CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body. Call a local poison control center for treatment information.

Button cell or coin batteries located inside the product are non-replaceable. Do not force discharge, recharge (non-rechargeable batteries are not to be recharged), disassemble, heat above manufacturer's specified temperature rating, or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.

14:**Disposal of Batteries** (if applicable): Remove and immediately recycle or dispose of used batteries according to local regulations and **keep away from children**. Even used batteries may cause severe injury or death. Do NOT dispose of batteries in household trash or incinerate. Overheated batteries can rupture or explode. If you are unsure of how or where to dispose of a battery, refer to your local ordinances for the proper location, method, etc.

- **Alkaline batteries & lithium button cell batteries**: You can safely dispose of alkaline and lithium button cell batteries with normal household waste. They do not pose a health or environmental risk during normal use or disposal. (Alkaline batteries are composed primarily of common metals like steel, zinc, and manganese.)
Do not dispose of large amounts of alkaline or lithium button cell batteries in a group. Used batteries are often not completely "dead." Grouping them together can bring these "live" batteries into contact with one another, creating safety risks. To avoid this, insulate each battery with tape or other non-conductive material to ensure it does not discharge. Proven cost-effective and environmentally safe recycling processes are not yet universally available for alkaline and lithium button cell batteries. Some communities offer recycling or collection of these batteries. For more information, refer to your local ordinances or contact your local government.
- **Lead-acid batteries**: Dispose of lead-acid batteries by bringing them to an electronic waste center or recycling center, or dispose of them in accordance with your local ordinances. (Rechargeable lead-acid batteries are the same type used in automobiles and should be disposed of in a similar fashion.)

Contact Us

After-Sales Service Tel:
1(970)364-2868

After Sales Email:
support@bolabutty.com