PLASTIC RAIN GAUGE

WATER MAGNIFIES MEASUREMENTS BY 35% FOR EASY READING —



To Measure Rainfall:


For accurate readings, place rain gauge in open area away from buildings, trees, or other obstructions.


Side Mount:

Mount rain gauge onto level surface. Anchor with 2-inch screws (not included).

Ground Mount:

Push rain gauge into level ground.





GROUND MOUNT

PRODUCT FACTS:

MEASUREMENT RANGES
Rainfall:

Rain gauge cannot be used in



AcuRite uses patented technology.
Visit www.acurite.com/patents for details.



0 - 72397 00830 1

