



WARRANTY CARD

Customer's Name & Address :

.....

.....

.....

Tel : Date :

Bill / Cash Memo No. :

Dealer's Stamp & Signature

For Customer Complaints, Contact:
Manager, Consumer Care Cell | Toll Free No.: 1800-425-6666
Email: customercare@stovekraft.com | Website: www.stovekraft.com

Imported, Marketed By & Customer Care Address:

Stove Kraft Pvt. Ltd.

An ISO 9001 : 2008 Certified Company
81, Harohalli Industrial Area, Kanakapura Taluk
Ramanagara District, Bangalore Rural - 562 112

Country of Origin: P.R.C.
Manufactured by: GHAG Co. Ltd., Guangdong Province, P.R.C.



AMAZE
ELECTRIC KETTLE



1.5
Litres

CAPACITY

1500
Watts

POWER

1
Year

WARRANTY

INSTRUCTION MANUAL AND WARRANTY CARD

WARRANTY TERMS AND CONDITIONS

Stove Kraft Pvt. Ltd., warrants to the purchaser of this Amaze Electrical Kettle for a period of 1Year commencing from the date of purchase of the product, the company will repair or replace free of charge any part or parts of the product, should the company be fully satisfied in its sole directions, that the defect/s is/are due to faulty material or workmanship only. The warranty will be governed by the following clauses.

- 1) The company or their Authorised Service Agent/Dealer will repair / replace all parts that are failing due to faulty material or defective workmanship pertaining to the above product.
- 2) Only the Company or its Authorised Service Agent / Dealer can service / repair or attend to install/reinstall the above product.
- 3) No on-site warranty will be executed. The warranty will be executed only at authorized service centers and in which the authorized representative / dealer is situated including outstation locations. All to and fro traveling and other incidental expenses as prevailing from time to time incurred in connection with the visit of the purchaser to the service location for the purpose of execution of warranty shall be borne by the said purchaser only.
- 4) The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement of defective parts and does not cover any consequential or resulting liability, damage or loss arising from such defects. Further more, the warranty in no case shall extend to the payment or any monetary consideration whatsoever, of the replacement or return of the product as a whole.
- 5) This warranty does not cover corrosive, plastic and glass components adding decorative value to the product.
- 6) The warranty is issued subject to Jurisdiction of Bangalore Court of law.
- 7) The warranty is covered by force Majeure clause. In the event of the above product struck by any natural Calamity, This Warranty stands Null & Void.

DEAR CUSTOMER

Welcome to the Stove Kraft family.

Congratulations on choosing AMAZE ELECTRICAL KETTLE

To get the best benefit of this Product, kindly go through the user manual* before using the Product. Pigeon products are manufactured with state-of-the-art technology. They offer a valuable hand in your cooking and they would integrate with your life style and be your reliable support. If however, for some reason, you need any assistance or help - please let us know we shall be happy to resolve your issues at the earliest.

Assuring you of our best services and hoping to have patronage for other Pigeon products as well.

Yours
Team Stove Kraft

***PLEASE KEEP THE MANUAL SAFELY FOR REFERENCE**

BEFORE USE, IT SHALL BE INSPECTED AS FOLLOWS :

1. Check and confirm if the power voltage complies with rated voltage of this product, the power socket can bear the normal load of this product and the power socket is available with reliable earthing device.
2. Put this product on the flat and solid floor.
3. It shall be away from fire, heating household electric appliance and combustible articles.
4. It shall be put in a place beyond the reach of children and available with power wire so as to avoid scalding or electric shock.

SAFETY PRECAUTIONS

1. This product is applicable for indoor water heating or boiling and not applicable for cooking of heating of any food.
2. Please be aware that the risk to children or disabled persons is not considered in product design.
3. It may reduce service life or cause potential risk when it is used under the environment of high temperature, much powder dust and corrosive gas, please take care.
4. The product can only be used on matched base and shall not be used on the base of other products. This base cannot be used by other products.
5. The connector between kettle and base cannot be used as a switch. Please use the power switch properly.
6. During water filling, the highest water level cannot be exceeded so as to prevent steam and hot water from ejecting or overflowing out of kettle nozzle.
7. This product is not provided with anti-dry burning power failure protection device, but dry burning shall be avoided as possible so as to extend service life.
8. During working, the metal surface on kettle body has high temperature and scalding shall be taken care.

DESIGNATION OF COMPONENTS

This photo is only for reference as an example. The physical article inside the package shall prevail.

PRODUCT PROFILE

This electric kettle with reasonable design will bring convenient and pleasant enjoyment for your life.

- Rapid water cooking, time and power saving
- Fine filter screen is used for filtration of impurities in water
- Steam induction controller, automatic power cut after water is boiling
- Dry burning protection power cut can ensure safety and reliability
- Transparent water level, clearly visual display
- It adopts high quality temperature controller
- 360 rotary base
- Noble and graceful stainless steel shell

USE INSTRUCTION

If the kettle is used the first time or it has not been used for long time, it is required to fill the water into the kettle to the maximum level, then boil the water once or twice, then empty the water so as to clean the kettle. For this moment, the water cannot be drunk.

1. After kettle cover is opened, remove the kettle from the power base, fill clean water into kettle. Take care not to exceed the maximum water level. Place the kettle cover properly and put it on the power base. The contact shall be in good condition.
2. Insert power wire into power supply and press switch button to light up the indicating lamp.
3. Lift the water kettle from the power base and empty water for drinking .
4. Press heat preservation switch to light up the indicating lamp, the kettle will start heat preservation, If heat preservation is not required, press heat preservation indicating lamp will go out.
5. The water shall be filled according to requirement. Too much water may cause unnecessary water.
6. If the kettle is not used for long time, please empty the remaining water out of kettle and make it dry in the air.

This photo is only for reference as an example. The physical article inside the package shall prevail. After the water is boiled, attention shall be paid to avoid scalding while opening the kettle cover.

CLEANING OF ELECTRIC KETTLE

The kettle body and base cannot be cleaned by putting them into water or spraying water on them. To extend the service life of kettle, the mineral sediment inside the kettle shall be cleaned on regular basis. Before cleaning, it is required to remove the power plug and make electric kettle cool down. Do not clean the inside of kettle and outside surface with steel wire and chemical or powder-like detergent.

CLEANING METHOD


1. Fill 0.5 liter edible white vinegar into kettle and soak it inside the kettle for more than 1 hour;
2. Empty the liquor out of the kettle and clean the residual sediment with wet cloth.
3. Fill water into the kettle and empty the water after boiling, rinse the kettle with clean water for 4 or 5 times. The kettle can be used again;
4. If necessary, repeat the above operation for several times;
5. The outside of kettle can be wiped up with wet cloth;
6. Remove the filter screen out of the kettle lightly, rinse with clean water or scrub with soft brush (metal brush is not allowed to use). After drying, insert the filter screen into the mouth.

AFTER-SALE SERVICE

1. The warranty period of electric kettle is six months (only applicable for products designed for family and hotel).
2. The starting date of warranty period is subject to the invoice date of product.
3. Any one of the following cases shall not be within the warranty range:
 - A. The damage is caused by improper use, storage and maintenance of consumers.
 - B. The damage is caused by disassembly and repair by service department not designated by our company.
 - C. No effective invoice is available.
 - D. Commercial use.
 - E. The damage is caused by force majeure.
4. For products within the warranty period, the customer service center of our company will serve you zealously.
5. In case of any fault with the product, please contact with special service network points or customer service center of our company.

Thank you for choosing our products. It is just one of a complete range of cleverly designed, safe and practical products which will help to make your life easier. Please read these instructions carefully to get the best results from this product.

DESIGNATION OF COMPONENTS



(Water level scale inside the kettle body)

SAFETY INSTRUCTIONS

1. No responsibility is accepted for damage resulting from improper use or non-compliance with the instructions.
2. The kettle is designed for heating water only. Never put any other liquid into the kettle, nor should it use another cooking appliance.
3. Before inserting the main plug into the socket check whether the supply line voltage and current rating are in compliance with the rated electric parameter shown on the kettle label.
4. Do not operate the kettle with wet hands.
5. Keep children away from the kettle which is either in heating or filled with hot water.
6. Prevent from scalding water or steam.
7. Pour away the very first water boiled with this kettle. Then it is ready for use.
8. Do not touch any part of the kettle except the handle when the kettle is fully filled with boiling water.
9. Pour out the boiling water in one time, in order to enable the temperature of the kettle to decline.
10. Remove the plug from the wall socket in following case,
 - a) after use
 - b) malfunction comes up
 - c) before cleaning
11. When removing the plug from the wall socket never pull on the power cord.
12. Regularly clean and scour out the kettle, but can't allow the kettle, especially the heating base, to be immersed in water.
13. The appliance must not be immersed in water;
14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety;
15. Children should be supervised to ensure that they do not play with the appliance,
16. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

OPERATION GUIDELINES

1. Filling water

- The capacity of filled water is limited by the ultimate line graduated on the kettle body. It should not be higher than the max line, nor lower than the minimum line.
- On filling water, care should be taken to avoid water column flowing on the kettle's outside surface.

2. Locating

- Place the kettle on a stable flat surface.
- Never heat the kettle on any wet surface, do not allow water to penetrate the electrical parts inside the kettle.
- Do not position the kettle on or near hot surface or near open flames.

3. Switching on

- Insert the main plug on the power cord into the wall socket.
- Please take care that the power cord must be well located and can't be caught on by a passerby
- push the restoring switch
- The red indicator lamp brights, it indicates that the kettle is in heating.

4. Boiling

- The kettle is automatically switch off several seconds after the water is boiling.
- The red indicator lamp goes out as switch off.

5. Restoring

- After the kettle has switch off, it will need sometime to cool down, Almost after 15 seconds, the kettle can be switched on again by manual restoring.
- if the red indicator lamp still goes out after pushing the restoring switch, it may be the case that the temperature sensing controller is still in hot condition and time must be taken for re-operating the kettle.

FEATURE

- 1) Concealed heating element with stainless steel kettle bottom, resulting in convenience to clean.
- 2) Temperature sensing controller-automatic switch-off when water is boiling.
- 3) Dry boiling protector-boil-dry safety cutoff.
- 4) Easy-lift hinged lid.
- 5) Rotary (360) cordless base lead to the convenience for use.
- 6) Shining body.

TECHNICAL DATA

Model No	AMAZE ELECTRICAL KETTLE
Rated Power	1500W
Voltage & Frequency	220V~50Hz
Capacity	1.5Ltr